


PARTS LIST


MAIN ASSEMBLY

Part #	Description	Part #	Description
10) 502-528	Brick Panel Base (Set of 3)	910-930	FireWizard™ Remote Control
502-901	Brick Panel Set Standard Brown	918-582	Manual FireWizard™
502-902	Brick Panel Set Standard Red		
11) 502-097	Log Stand	910-215/P	Fan 115 VAC / 110 Cfm (dual blower)
12) 502-033	Front Air Box	910-073	Spark Generator Battery Holder
13) 948-450	Burner Tube Front NG/LP	910-074	Spark Generator Switch C/W Wire
14) 948-462	Burner Tube Rear NG/LP		
15) 502-009	Log Tray	910-813	Power Cord 120VAC Plug in Fan
503-930	Log Set - (Oak)	910-927	Wire Harness Twin Fan
16) 502-016	Top Brick Clip	910-928	Wire Harness Solenoid Switch
20) 910-929	Control Module	910-939	Wire Sparker - Combo Drive
21) 910-931	Power Module	910-935	Switch Manual Control
		910-528	Wire - 54 in.
		918-566	Manual



VALVE TRAY ASSEMBLY

Part #	Description
120) 904-644	Orifice # 35
121) 904-568	Orifice # 44
122) 910-008	Pilot Assembly
125) 910-460	Valve NG - SIT 825
126) 910-937	Valve Solenoid - 3 Volt
127) 910-928	Wire Harness Solenoid Switch
128) 910-925	Wire Harness J2
910-924	Wire Harness J1
910-926	Wire Harness J3
129) 502-041	Cable Aeration Control
502-574/P	Valve Assembly - NG
502-576/P	Valve Assembly - LP
502-969	Conversion - LP



PARTS LIST

FLUSH DOOR & LOUVERS

Part #	Description
502-910	Flush Louvers (Set) - Black
133) *	Flush Louver - Top
134) *	Flush Louver - Bottom
135) 940-349/P	Glass (Flush)
138) 502-003	Flush Door Frame
139) 936-155	Glass Gasket (Tadpole)
140) 948-042	Spring Hinge
502-924	Finishing Trim - Black
141) *	Trim Side Left
142) *	Trim Side Right
143) *	Trim Top
188) 948-216	Regency® Logo Plate

*Not available as a replacement part.

