


WIRING DIAGRAM

This appliance does not require a 120V A.C. supply for operation.



Important: The AA batteries in the battery pack operate the burner switch. If the batteries become weak they will need to be replaced with quality alkaline batteries. This unit will not operate without AA batteries.