


MAINTENANCE

U43 REPLACEMENT / SPARE PARTS LIST

Part #	Name	Description	Part #	Name	Description
1) 650-933	Log Set	3 logs	15) 591-590/P	Valve Assembly	(NG)
2) 902-151	Embers	1 bag	16) 591-591/P	Valve Assembly	(LP)
3) 902-153	Rockwool	1 bag	17) 651-578/P	Burner	(NG)
4) 940-235	Wraparound Glass		18) 651-575/P	Burner	(LP)
5) 940-227	Mitred Glass	Large Center	19) 650-915	Fan Assembly	
6) 940-226	Mitred Glass	Small Side (each)	20) 910-157	Fan Motor	
7) 940-225	Panel Glass	Large Center	21) 910-384	Pilot Assembly	(NG)
8) 940-226	Panel Glass	Small Side (each)	22) 910-385	Pilot Assembly	(LP)
9) 650-920	Door Gasket		23) 910-341	Thermopile	
10) 910-190	Piezo Ignitor		24) 910-386	Thermocouple	
11) 910-330	Variable Speed Control				
12) 910-246	On/Off Switch				
13) 910-378	Valve	(NG)			
14) 910-380	Valve	(LP)			



U28 REPLACEMENT / SPARE PARTS LIST

Part #	Name	Description	Part #	Name	Description
1) 560-933	Log Set	3 logs	15) 560-520/P	Valve Assembly	(NG)
2) 902-151	Embers	1 bag	16) 560-523/P	Valve Assembly	(LP)
3) 902-153	Rockwool	1 bag	17) 560-510/P	Burner	(NG)
4) 940-238	Wraparound Glass		18) 560-515/P	Burner	(LP)
5) 940-237	Panel/Mitred Glass Large Center		19) 560-517	Fan Assembly	
6) 940-236	Panel/Mitred Glass Small Side (each)		20) 910-331	Fan Motor	
7) 560-032	Glass Extrusion		21) 910-384	Pilot Assembly	(NG)
8) 650-920	Door Gasket		22) 910-385	Pilot Assembly	(LP)
10) 910-190	Piezo Ignitor		23) 910-341	Thermopile	
11) 910-330	Variable Speed Control		24) 910-386	Thermocouple	
12) 910-246	On/Off Switch				
13) 910-378	Valve	(NG)			
14) 910-380	Valve	(LP)			

