


MAIN ASSEMBLY

Part #	Description	Part #	Description
1) 560-920	Louver Assy - Gold	27) 910-233	Thermodisc
560-921	Louver Assy - Brush Nickel	28) *	Mounting Bracket - Thermodisc
560-922	Louver Assy - Black	29) *	Air Deflector
9) 730-560	Relief Door Assembly	30) 680-019	Rear Panel
10) 730-034	Mounting Plate Gasket	31) 630-021	Fan Access Panel
		32) 730-565	Firebox Baffle
11) 730-517/P	Fan Assembly (120 V)	33) 640-520	False Top Assembly
910-331/P	Fan Motor	38) 820-058	Pedestal Base Cover
12) 910-794	Power Cord (120 V)	45) 946-204	45° Elbow
15) *	Pedestal Assembly	910-073	Spark Generator Battery Holder
16) 730-039	Pedestal Door	910-074	Spark Generator Switch c/w Wire
17) 904-257	Pedestal Door Magnet		
18) 560-025	Pedestal Back	640-944	Horizontal Termination Venting Kit
		640-530/P	Riser Terminal
19) 730-530	Side Panel Door Assy (Right Side)	948-216	Logo Plate
20) 730-525	Side Panel Door Assy (Left Side)	918-529	Manual
21) 560-031	Side Panel Door Hinge		
23) 904-258	Side Panel Door (c/w Hook) Magnet		
24) 948-255	Door Latch		
25) *	Flex Pipe (3" ID)		
26) *	Clamp for Flex Pipe		


*Not available as a replacement part.

OPTIONAL
45 DEG. ELBOW(SEPARATE ILLUSTRATION ON
OTHER GLASS DOOR FRONTS)

BURNER & LOG ASSEMBLY

Part #	Description
51)	910-241 Burner ON/OFF Switch (3-way)
52)	910-190 Piezo Ignitor & Nut
53)	904-586 Knob - Fan Control Switch
54)	910-373 Knob - Pilot Valve Extension
55)	910-372 Flame Adjusting Knob
56)	908-646 Control Panel Decal
57)	650-220 Control Panel Plate
58)	910-330 Fan Speed Control (120 V)
680-574/P	Valve Assembly - Natural Gas
680-576/P	Valve Assembly - Propane
60)	910-478 Valve - S.I.T. - NG/LP
66)	910-038 Pilot Assy - S.I.T. - 3 Flame NG
	910-039 Pilot Assy - S.I.T. - 3 Flame LP
	904-240 #37 Orifice - N.G.
	904-390 #52 Orifice - Propane
	936-170 Orifice Gasket
67)	* Pilot Holder
68)	W840470 Pilot Assembly Gasket
71)	730-528 Rear Bracket Assembly
75)	730-935 Log Set
78)	730-550 Burner Assy - NG/LP
80)	260-565 Air Shutter Gear Assembly (Female)
81)	904-565 Hex Key 3/16" AF
82)	630-009 Gasket - Burner Tray / Air Passage
83)	630-008 Gasket - Burner Tray / Firebox
84)	* Air Shutter Gear Assembly (Male)

*Not available as a replacement part.



DOOR ASSEMBLIES

Part #	Description
730-923	Brush Nickel Mitred Door - Complete
730-924	Gold Mitred Door - Complete
730-926	Black Mitred Door - Complete
730-932	Gold Wrap Door - Complete
730-928	Gold Panel Door - Complete
101) 650-920	Door Gasket Kit
105) *	Ceramic Paper
106) 940-323/P	Side Glass
107) 936-243	Glass Gasket
108) 940-322/P	Centre Glass
111) *	Door Frame Fibre Paper
112) 750-015	Door Glass Extrusion
208) 940-325/P	Wrap Glass

*Not available as a replacement part.

