


**MAIN ASSEMBLY**

Part #	Description		
2) 910-078	Battery AA	904-658	Inlet Gas Flex Line SS
910-363	White Wall Switch	430-011	Flue Collar Gasket
910-366	White Switch Plate Wire	596-047F	Relief plate door
3) 596-008	Bottom Cover NG / LP	596-048	Plate Relief Gasket
4) 596-525	Burner Assembly -NG	596-089	Valve Tray Gasket
596-530	Burner Assembly-LP	430-011	Inner Flue Collar Gasket
5) 596-574/P	Valve Assembly -NG	586-017F	Flue Restrictor Plate
596-576/P	Valve Assembly-LP	586-016F	Gas line cover
6) 911-004	886 Sit Valve - NG	596-068	Top nailing strip
911-005	886 Sit Valve - LP	596-045	Side nailing strip
7) 911-006	Pilot Assembly - NG	596 072	Bottom nailing strip
911-007	Pilot Assembly - LP	940-361/P	Flush Glass / c/w gasket
8) 904-593	Orifice # 40 (NG)	586-029	Flush Glass Frame (shown on next page)
904-345	Orifice # 53 (LP)	910-882	Wire (Valve to Burner ON/OFF)
9) 948-484	Slide Hinge	918-932	Manual



# PARTS LIST

Part #	Description
10) 596-907	Reflective Stainless Steel Inner Panels
596-908	Black Enamel Inner Panels
11) 586-914	Faceplate Black
586-916	Faceplate Sunset Bronze
586-917	Faceplate Brushed Stainless
946-671	Cobalt Blue Glass Crystals
946-672	Natural River Pebbles
946-673	White River Pebbles
946-674	Ceramic Spa Stones
946-680	GT Proflame Remote Control
946-681	GTM Proflame Remote Control
946-683	GTM NG Modulator
946-684	GTM LP Modulator
910-574	GTM Wire Harness
910-576	Cover Wall Mount (white)
910-572	Receiver GTM SIT w/Batt & Cover

