


MAIN ASSEMBLY

Part #	Description	Part #	Description
1)	420-122 Fan Access Panel	41)	420-157 Gasket - Transition Box Bottom
2)	420-142 Gasket - Fan Access Panel	42)	420-054 Gasket - Transition Box Top
	422-518/P Fan Assembly:	43)	* Stove Top
3)	910-215/P Fan Motor (120 V)	44)	420-048 Thermal Insulation
5)	910-750 Power Cord (120 V)	45)	* Adaptor Stop
	910-752 Wire Harness (intermediate)	46)	* Adaptor Holding Brkt-Left
7)	910-142 Thermodisc-Fan Auto ON/OFF	47)	* Adaptor Holding Brkt-Right
8)	* Fan Switch Cover	48)	320-518 Flue Adaptor Assy
9)	* Thermodisc Bracket	50)	* Insulation Hold Down Brkt
10)	420-140 Flue Restrictor		
12)	* Air Hood	51)	420-170 Top Fan Air Channel
13)	* Levelling Bolt 5/16 x 3" Hex Hd	52)	420-171 Upper Fan Air Channel
14)	948-045 Jack Chain	53)	420-172 Lower Fan Air Channel
15)	948-247 Spring Lever Handle		
16)	948-025 Door Extension Spring		
17)	* Wire Holder Clip		
18)	* Strain Relief		
19)	* Grommet for Power Cord		
	512-969 Conversion Kit to Propane		
	948-220 Logo Plate - Hampton		
	918-351 Manual		
21)	420-920 Flush Louvers (Set) - Black/Gold		
	420-922 Flush Louvers (Set) - Black		
	420-923 Flush Louvers (Set) - Black/Steel		
25)	420-940 Bay Louvers (Set) - Black/Gold		
	420-938 Bay Louvers (Set) - Black		
	420-942 Bay Louver (Set) - Black/Steel		
	422-928 Brick Panel Set - Standard		
	422-901 Brick Panel Set - Standard Brown		
	422-902 Brick Panel Set - Standard Red		
	422-903 Brick Panel Set - Herringbone Brown		
	422-904 Brick Panel Set - Herringbone Red		
33)	* Brick Panel - Right Side		
34)	* Brick Panel - Left Side		
35)	* Brick Panel - Back		
36)	400-090 Brick Clip		

*Not available as a replacement part.




PARTS LIST

BURNER ASSEMBLY & LOG SET

Part #	Description
423-574/P	Valve Assembly - NG
423-576/P	Valve Assembly - LP
52) 910-378	Valve - SIT NG
910-380	Valve - SIT LP
53) 910-190	Ignitor Piezo and Nut
55) *	Valve Tray
58) 904-240	Burner Orifice Nat. Gas #37
904-390	Burner Orifice LP # 52
936-170	Orifice Gasket
66) 910-038	Pilot Assembly - 3 Flame (NG)
910-039	Pilot Assembly - 3 Flame (LP)
67) *	Pilot Holder
68) W840470	Pilot Assembly Gasket
69) 402-935	Log Set
402-572	Ember Package
70) 420-143	Valve Tray Gasket
71) 402-526	Grate/Diffuser Assy
72) 402-519	Burner Assembly (NG/LP)
73) *	Log Tray Mount Bracket
74) *	Log Tray Rear
90) 910-421	Pilot ON/OFF 3" (SIT)
91) 910-422	Extension Knob
	HI/LOW 3" (SIT)
	Extension Knob


*Not available as a replacement part.



BAY & FLUSH FRONT ASSEMBLY

Part #	Description
Bay Door	
420-931	Complete Bay Door with Black Trim
102)*	Glass Retainer Side (Top & Btm)
103)*	Glass Retainer Front (Top & Btm)
106) 940-315/P	Side Glass
107) 936-243	Gasket
108) 940-314/P	Center Glass
110) 902-183	Bay Brick Panel - Standard
402-905	Bay Brick Panel - Standard Brown
402-906	Bay Brick Panel - Standard Red
111)*	Door Trim
112) 904-196	1" Round Magnet
910-421	Pilot On/Off 3" Extension Knob (SIT)
910-422	Flame Hi/Low 3" Extension Knob (SIT)
402-956	Gold Trim Bay Front
402-958	Steel Trim Bay Front
113) 422-960	Bay Front Screen

*Not available as a replacement part.



Flush Door	
422-530	Complete Flush Door Assy
112) 904-196	1" Round Magnet
135) 940-307/P	Flush Glass
137) 904-691	UClip
139) 936-155	Tadpole Glass Gasket
149) 420-932	Flush Trim Top/Btm (Set) -Gold
422-943	Screen Door (Optional)
171) 512-546	Door Latch Assembly
173) 430-133	Handle
904-712	U-clip for frame

PARTS LIST

FACEPLATE ASSEMBLY

Part # Description

402-919 Complete Faceplate (Set) Contour with Black Trim-Oversize

- 51) * Faceplate Side Right - Oversize
- 59) * Faceplate Top - Oversize
- 60) * Faceplate Side Left Assy-Oversize
- 402-534 Trims Pkg. Black - Oversize, Zero Clearance
- 65) * Faceplate Trim Right - Oversize
- 68) * Faceplate Trim Top - Oversize
- 70) * Faceplate Trim Left Assy - Oversize

- 97) 910-246 2-way Gold Contact Switch
- 98) 910-330 Fan Speed Control (120 V)
- 99) 904-569 Fan Speed Control Knob (120 V)

400-917 Complete Custom Faceplate (Set)

- 71) * Faceplate Side Right - Custom
- 72) * Faceplate Top - Custom
- 73) * Faceplate Side Left - Custom


- 74) 904-586 Speed Control Knob
c/w Spring Clip

Part # Description

- 400-950 Hearth Trim 1" - Regular
- 320-940 Hearth Trim 1" - Oversize
- 400-926 Hearth Trim 2" - Regular
- 320-942 Hearth Trim 2" - Oversize
- 180) 400-928 Hearth Trim 4" - Regular
- 181) 320-944 Hearth Trim 4" - Oversize
- 400-959 Hearth Trim 6" - Regular
- 320-946 Hearth Trim 6" - Oversize

- 190) * Screw #8 x 1/2" Black self-tapping
- 191) * Screw #8 x 1/2" Brass self-tapping
- 199) 948-216 Regency Logo Plate

*Not available as a replacement part.



402-918 Complete Faceplate (Set) Standard Contour with Black Trim

- 91) * Faceplate Side Right - Standard
- 92) * Faceplate Top - Standard
- 93) * Faceplate Side Left Assy - Standard
- 402-532 Trims Pkg. - Standard Black
- 402-950 Trim Set Pkg. - Standard Contour Brass
- 94) * Faceplate Trim Right - Standard
- 95) * Faceplate Trim Top - Standard
- 96) * Faceplate Trim Left Assy - Standard

- 97) 910-246 2-way Gold Contact Switch
- 98) 910-330 Fan Speed Control (120 V)
- 99) 904-569 Fan Speed Control Knob (120 V)

402-933 Complete Faceplate (Set) Molded

- 141) * Faceplate Side Right - Molded
- 142) * Faceplate Top - Molded
- 143) * Faceplate Side Left -Molded
- 144) * Mounting Bracket - Right
- 145) * Filler Bracket
- 146) * Mounting Bracket - Left
- 147) * Screw #8 x 3/4" Pan Head

HAMPTON CAST - FACEPLATE ASSEMBLY

Part #	Description
402-971**	Cast Faceplates (Set)
187) 910-246	Burner On/Off Switch
188) 910-330	Fan Speed Control (120 V)
189) 904-733	Knob - Black Cast Surround
201)*	Cast Faceplate - Right
202)*	Cast Faceplate - Top
203)*	Cast Faceplate - Left
205)*	Flush Glass Frame
194)*	Mounting Flange
195)	Hampton Logo Plate
207) 402-981**	Cast Grill (Set) - Top & Bottom

*Not available as a replacement part.

** Last digit of part number represents colour:
 1=Black Metallic, 5=Enamel Brown, 6=Enamel Black

