


MAIN ASSEMBLY

Part #	Description
1)	420-122 Fan Access Panel
2)	420-142 Gasket - Fan Access Panel
3)	910-215/P Fan Assembly:
4)	910-215/P Fan Motor (120 V)
5)	910-750 Power Cord (120 V)
6)	910-752 Wire Harness (intermediate)
7)	910-142 Thermodisc-Fan Auto ON/OFF
8)	* Fan Switch Cover
9)	* Thermodisc Bracket
10)	420-140 Flue Restrictor
12)	420-119 Air Hood
13)	* Levelling Bolt 5/16 x 3" Hex Hd
14)	948-045 Jack Chain
15)	948-247 Spring Lever Handle
16)	948-025 Door Extension Spring
17)	* Wire Holder Clip
18)	* Strain Relief
19)	* Grommet for Power Cord
514-972	Conversion Kit to Propane
918-846	Manual
21)	420-920 Flush Louvers (Set) - Black/Gold
420-922	Flush Louvers (Set) - Black
420-923	Flush Louvers (Set) - Black/Steel
422-901	Brick Panel Set - Standard Brown
422-902	Brick Panel Set - Standard Red
422-903	Brick Panel Set - Herringbone Brown
33)	* Brick Panel - Right Side
34)	* Brick Panel - Left Side
35)	* Brick Panel - Back
36)	400-090 Brick Clip
41)	420-157 Gasket - Transition Box Bottom
42)	420-054 Gasket - Transition Box Top
43)	* Stove Top
44)	420-048 Thermal Insulation
45)	* Adaptor Stop

Part #	Description
46)	* Adaptor Holding Brkt-Left
47)	* Adaptor Holding Brkt-Right
48)	320-518 Flue Adaptor Assy
50)	* Insulation Hold Down Brkt
51)	420-170 Top Fan Air Channel
52)	420-171 Upper Fan Air Channel
53)	420-172 Lower Fan Air Channel


*Not available as a replacement part.



BURNER ASSEMBLY & LOG SET


Part #	Description
423-574/P	Valve Assembly - NG
423-576/P	Valve Assembly - LP
52) 910-478	Valve - SIT NG / LP
53) 910-190	Ignitor Piezo and Nut
55) *	Valve Tray
58) 904-240	Burner Orifice Nat. Gas #37
904-390	Burner Orifice LP # 52
936-170	Orifice Gasket
66) 910-038	Pilot Assembly - 3 Flame (NG)
910-039	Pilot Assembly - 3 Flame (LP)
67) *	Pilot Holder
68) W840470	Pilot Assembly Gasket
425-930	Log Set
70) 420-143	Valve Tray Gasket
71) 402-526	Grate/Diffuser Assy
72) 402-519	Burner Assembly (NG/LP)
73) *	Log Tray Mount Bracket
74) *	Log Tray Rear
90) 910-421	Pilot ON/OFF 3" (SIT) Extension Knob
91) 910-422	HI/LOW 3" (SIT) Extension Knob

*Not available as a replacement part.



FLUSH FRONT ASSEMBLY

Part #	Description
	Flush Door
422-530	Complete Flush Door Assy
112) 904-196	1" Round Magnet
135) 940-307/P	Flush Glass
137) 904-691	U Clip
139) 936-155	Tadpole Glass Gasket



FACEPLATE ASSEMBLY

Part # Description

402-919 Complete Faceplate (Set) Contour with Black Trim-Oversize

- 51) * Faceplate Side Right - Oversize
- 59) * Faceplate Top - Oversize
- 60) * Faceplate Side Left Assy-Oversize
- 402-534 Trims Pkg. Black - Oversize, Zero Clearance
- 65) * Faceplate Trim Right - Oversize
- 68) * Faceplate Trim Top - Oversize
- 70) * Faceplate Trim Left Assy - Oversize

- 97) 910-246 2-way Gold Contact Switch
- 98) 910-330 Fan Speed Control (120 V)
- 99) 904-569 Fan Speed Control Knob (120 V)

400-917 Complete Custom Faceplate (Set)

- 71) * Faceplate Side Right - Custom
- 72) * Faceplate Top - Custom
- 73) * Faceplate Side Left - Custom


- 74) 904-586 Speed Control Knob
c/w Spring Clip

Part # Description

- 180) **400-950** **Hearth Trim 1" - Regular**
- 181) **320-940** **Hearth Trim 1" - Oversize**
- 180) **400-926** **Hearth Trim 2" - Regular**
- 181) **320-942** **Hearth Trim 2" - Oversize**
- 180) **400-928** **Hearth Trim 4" - Regular**
- 181) **320-944** **Hearth Trim 4" - Oversize**
- 180) **400-959** **Hearth Trim 6" - Regular**
- 181) **320-946** **Hearth Trim 6" - Oversize**

- 190) * Screw #8 x 1/2" Black self-tapping
- 191) * Screw #8 x 1/2" Brass self-tapping
- 199) 948-216 Regency® Logo Plate

*Not available as a replacement part.




402-918 Complete Faceplate (Set) Standard Contour with Black Trim

- 91) * Faceplate Side Right - Standard
- 92) * Faceplate Top - Standard
- 93) * Faceplate Side Left Assy - Standard
- 402-532 Trims Pkg. - Standard Black
- 402-950 Trim Pkg. - Standard Brass
- 94) * Faceplate Trim Right - Standard
- 95) * Faceplate Trim Top - Standard
- 96) * Faceplate Trim Left Assy - Standard

- 97) 910-246 2-way Gold Contact Switch
- 98) 910-330 Fan Speed Control (120 V)
- 99) 904-569 Fan Speed Control Knob (120 V)

CONTEMPORARY FACEPLATE AND DOORFRAME

Part #	Description
1) 425-512	Door Bottom Assembly
2) 425-513	Frame Inside
3) 425-514	Faceplate Outside
4) 425-942	Hearth Trim



LOW PROFILE FACEPLATE

Part # 425-924 Description

- 1) * Backplate Assembly
- 2) * Bottom Louver
- 3) * Right mounting bracket
- 4) * Left mounting bracket
- 5) * Front Frame

