


PARTS LIST

MAIN ASSEMBLY

Part #	Description
1)	320-009 Fan Access Plate
2)	320-079 Gasket - Fan Access Plate
	320-517/P Fan Assembly 120 V
3)	910-331/P Fan Motor 120 V
5)	910-750 Power Cord
	910-752 Wire Harness (Faceplate)
7)	910-142 Fan Auto On/Off Thermodisc
8)	* Thermodisc Bracket
9)	320-070 Fan Switch Cover
13)	* Baffle Plate
14)	948-045 #12 Jack Chain
15)	948-247 Door Handle
16)	948-025 Door Spring
17)	* Wire Holder Clip
18)	* Strain Relief
19)	* Grommet for Power Cord
	320-924 Flush Louvers (Set) - Black/Gold
	320-922 Flush Louvers (Set) - Black
	320-925 Flush Louvers (Set) - Black/Steel
21)	* Top Flush Louver
23)	* Bottom Flush Louver
	320-932 Bay Louvers (Set) - Black/Gold
	320-934 Bay Louvers (Set) - Black
	320-935 Bay Louvers (Set) - Black/Steel
25)	* Top Bay Louver
27)	* Bottom Bay Louver
	320-928 Brick Panel Set - Standard
	320-901 Brick Panel Set - Standard Brown
	320-902 Brick Panel Set - Standard Red
	320-903 Brick Panel Set - Herringbone Brown
	320-904 Brick Panel Set - Herringbone Red
33)	* Brick Panel - Right
34)	* Brick Panel - Left
35)	* Brick Panel - Back
36)	400-090 Brick Clip
40)	* Top Support
41)	* Collar Support
42)	320-077 Collar Gasket
43)	* Stove Top
44)	420-048 Thermal Insulation
45)	* Adaptor Stop
46)	* Adaptor Holding Brkt - Left
47)	* Adaptor Holding Brkt - Right
48)	320-518 Flue Adaptor Assembly
50)	* Insulation Hold Down Bracket
51)	* Louver Hold Down - Top
	908-172 Manual

* Not available as a replacement part.



BURNER & LOG ASSEMBLY


Part #	Description
52) 320-078	Gasket - Valve Tray
54) 910-421	Pilot ON/OFF 3" Extension Knob (with Bay Front)
55) 910-422	Flame Hi/Low 3" Extension Knob (with Bay Front)

320-563/P	Valve Assembly - NG
320-564/P	Valve Assembly - LP
56) 910-190	Piezo Ignitor and Nut
57) 910-378	Valve - S.I.T. - Natural Gas
910-380	Valve - S.I.T. - Propane
59) *	Valve Tray
66) 910-034	Pilot Assy-3 Flame-S.I.T.-NG
910-035	Pilot Assy - 3 Flame - S.I.T. - LP
67) 904-689	Orifice #33 - NG
904-641	Orifice #50 - LP
936-170	Orifice Gasket

79) 320-550	Burner Assy - NG
320-551	Burner Assy - LP
82) 320-001	Burner Grate
84) 320-034	Log Tray Rear

600-964	Log Set
86) 902-202	Front Log - Right
87) 902-201	Front Log - Left
88) 902-026	Rear Log

* Not available as a replacement part.




PARTS LIST

FLUSH DOOR AND BAY FRONT ASSEMBLY

Part #	Description	Part #	Description
Bay Front		Flush Front	
320-930	Bay Front Complete	149)	320-927 Complete Flush Trim (Top & Bottom) - Gold
102)	* Flush Glass Retainer	320-530	Flush Door Assy Complete with glass
106)	940-318/P Side Glass	131)	* Flush Door Frame
107)	936-243 Gasket	135)	940-316/P Glass - Flush
108)	940-317/P Center Glass	137)	904-691 UClip
110)	902-223 Bay Brick Panel - Standard	139)	936-155 Glass Gasket
	320-905 Bay Brick Panel - Standard Brown	320-943	Double Door Screen Complete
	320-906 Bay Brick Panel - Standard Red	173)	904-712 U-Clip for Frame
111)	* Door Trim	174)	511-085 Door Handle
112)	904-196 Magnet 1" Round	175)	511-084 Door Latch
	910-421 Pilot On/Off 3" Extension Knob		
	910-422 Flame Hi/Low 3" Extension Knob		
	320-936 Optional Bay Door Trim - Gold		
113)	320-960 Bay Front Screen		
	320-956 Gold Trim Bay Front		
	320-958 Steel Trim Bay Front		

* Not available as a replacement part.



FACEPLATES, TRIMS, AND HEARTHTHS

Part #	Description	Part #	Description
320-917	Complete Custom Faceplate (Set)	320-933	Molded Faceplate (Complete)
71)	* Faceplate Side Right - Custom	141)	* Molded Faceplate - Right
72)	* Faceplate Top - Custom	142)	* Molded Faceplate - Top
73)	* Faceplate Side Left - Custom	143)	* Molded Faceplate - Left
320-948	Faceplates and Trim (Complete) with Black Trim	144)	* Mounting Bracket - Right
74)	904-569 Fan Speed Control Knob	145)	* Filler Bracket
91)	* Faceplate Side - Right	146)	* Mounting Bracket - Left
92)	* Faceplate - Top	147)	* Screw #8 - 3/4" Pan Head
93)	* Faceplate Side - Left Assy		
320-553	Trim Set Packaged - Black	172)	320-940 Hearth Trim - 1"
320-950	Trim Set Packaged - Brass	176)	320-942 Hearth Trim - 2"
94)	* Trim Side - Right	180)	320-944 Hearth Trim - 4"
95)	* Trim - Top	184)	320-946 Hearth Trim - 6"
96)	* Trim Side - Left Assy	186)	904-586 Speed Control Knob c/w Spring Clip
		190)	* Screw #8 x 1/2" Black Self-tapping
97)	910-246 Burner ON/OFF Switch	191)	* Screw #8 x 1/2" Brass Plated Self-tapping
98)	910-330 Fan Speed Control 120 V	199)	948-216 Regency Logo
99)	* Faceplate Filler		* Not available as a replacement part.

