

U28 REPLACEMENT / SPARE PARTS LIST

Part #	Name	Description	Part #	Name	Description
1)	560-933	Log Set	3 logs	15)	560-520/P Valve Assembly (NG)
2)	902-151	Embers	1 bag	16)	560-523/P Valve Assembly (LP)
3)	902-153	Rockwool	1 bag	17)	560-510/P Burner (NG)
4)	940-238	Wraparound Glass		18)	560-515/P Burner (LP)
5)	940-237	Panel/Mitred Glass Large Center		19)	560-517 Fan Assembly
6)	940-236	Panel/Mitred Glass Small Side (each)		20)	910-331 Fan Motor
7)	560-032	Glass Extrusion		21)	910-384 Pilot Assembly (NG)
8)	650-920	Door Gasket		22)	910-385 Pilot Assembly (LP)
10)	910-190	Piezo Ignitor		23)	910-341 Thermopile
11)	910-330	Variable Speed Control		24)	910-386 Thermocouple
12)	910-246	On/Off Switch			
13)	910-378	Valve	(NG)		
14)	910-380	Valve	(LP)		

