


# PARTS LIST

## P121-2 (SEE THRU) MAIN ASSEMBLY

Part #	Description	Part #	Description	Part #	Description
1)	360-528 Door Assy Front - Tempered 360-538 Door Assy Front - Ceramic (Optional)	98)	910-366 Switch Cover Plate	181) *	Extension Trim - See Thru
2)	360-529 Door Assy Side - Tempered 360-539 Door Assy Side - Ceramic (Optional)	99)	910-363 Wall Switch	204)	360-940 Dec. Grill Front - Black (set)
9)	360-046 Nailing Strip - Top - Front	100)	910-367 Switch Receptacle Plastic Box	205)	948-216 Regency® Logo Plate
10)	360-047 Nailing Strip - Top - Side	910-882	Wire - Valve to Burner Switch	206)	910-171 Fan Axial 115V
11)	430-001 Standoff - Top	135)	360-069 Heat Shield - Side	207)	910-142 Thermodisc
17)	360-086 Gasket - Relief Door	146)	360-033 Left Side Door Trim	918-519	Manual
24)	* Relief Door Assembly	360-034	Right Side Door Trim		
32)	362-528 Brick Panel Base (Set of 6)	150)	360-123 Magnet Bracket - Front		
34)	902-603 Brick Panel - Std. Red (Side)	151)	904-258 Magnet		
		168)	360-068 Door Cover Assembly - Side		
		171)	360-920 Louver Front - Black (set)		
		360-922	Louver Front - Black/Gold (set)		
		360-924	Louver Front - Black/Steel (set)		



# PARTS LIST

## P121-2/P131-2 BURNER ASSEMBLY & LOG SET

Part #	Description
360-930	Log Set
41) *	Front Right Log
42) *	Front Left Log
43) *	Middle Left Log
44) *	Middle Right Log
360-574/P	Valve Assembly
56) 910-478	Valve S.I.T. - NG/LPG
57) 360-090	Gasket - Valve Tray
58) *	Valve Tray
66) 910-038	Pilot Assembly - NG
910-039	Pilot Assembly - LPG
67) *	Pilot Holder
68) W840470	Pilot Assembly Gasket
69) 910-190	Piezo Ignitor and Nut
79) 360-525	Burner Assembly
82) 360-027	Grate Assembly
904-690	Orifice #31 - NG
936-170	Orifice Gasket

\*Not available as a replacement part.

