


parts list

P131E-11 (Pier) Main Assembly

	Part #	Description
1.	360-528	Door Assy Front - Tempered
	360-946	Door Assy Front - Ceramic (Optional)
2.	360-529	Door Assy Side - Tempered
5.	363-000	Safety Screen (Each)
6.	363-002	Horizontal bracket (Each)
**	363-004	Vertical Bracket (Each)
7.	363-001	Safety Screen
8.	363-003	Horizontal Bracket (Each)
9.	360-046	Nailing Strip - Top - Front
10.	360-047	Nailing Strip - Top - Side
11.	430-001	Standoff - Top






	Part #	Description
17.	360-086	Gasket - Relief Door
24.	*	Relief Door Assembly
32.	362-528	Brick Panel Base (Set of 4)
34.	902-603	Brick Panel - Side Std. Red
141.	360-031	Column Finishing Trim
146.	360-034	Door Trim Right
147.	360-033	Door Trim Left
148.	360-035	Finishing Trim
149.	360-122	Magnet Bracket - Corner
150.	360-123	Magnet Bracket - Front
151.	904-258	Magnet

	Part #	Description
171.	360-920	Louver Front - Black (set)
224.	360-924	Louver Front - Black/Steel (set)
	360-942	Dec. Grill Side - Black (set)
173.	360-932	Louver Side - Black (set)
181.	360-532	Extension Trim - Pier
204.	360-940	Dec. Grill Front - Black (set)
206.	910-171	Fan Axial 115V
**	360-148F	Blower Screen
	948-223	Regency® Logo Plate
	920-016	Manual
*Not available as a replacement part.		
**Not Shown		



P121E-11/P131E-11 Burner Assembly & Log Set

	Part #	Description
40.	360-930	Log Set
41.	*	Front Right Log
42.	*	Front Left Log
43.	*	Middle Left Log
44.	*	Middle Right Log
	363-774/P	Valve Assembly -NG
	363-776/P	Valve Assembly -LP
56.	911-084	Valve Only -NG
	911-085	Valve Only -LP
57.	360-090	Gasket - Valve Tray
66.	911-276	Pilot Assembly - NG
	911-277	Pilot Assembly - LPG
67.	*	Pilot Holder
68.	W840470	Pilot Assembly Gasket
79.	360-525	Burner Assembly
82.	360-027	Grate Assembly
	904-690	Orifice #31 - NG
	904-641	Orifice #50 - LP
	936-170	Orifice Gasket
	910-036	Pilot Orifice NG
	910-037	Pilot Orifice LP
	911-010	Stepper motor NG
	911-011	Stepper motor LP
	910-432	Pilot tube with nuts
	911-039	2 way pilot hood
	911-037	Flame Sensor
	911-038	Spark Electrode
	911-187	Remote Battery Box
	911-127	Remote battery compartment door
	911-175	GTMF Remote control Hand held
	W840470	Pilot assembly gasket
	911-192	120 Volt Power Cord
	911-266/P	IFC Proflame Control Module
	911-257	Fan 2 Pin Wire Harness
	911-287	Fan Wire - Black
	911-288	Fan Wire - White
	911-173	Valve Wiring Harness
	911-181	Battery Box Wiring Harness
	911-193	Connector with Jumper Wire
	363-154	IFC Metal Cover - Base
	363-155	IFC Metal Cover - Top
	911-210	External Antenna IFC



*Not available as a replacement part.