


Parts Diagram




Parts List

Key	Part N°	Description	Qty.
1	25480	Access Panel	1
2	69518	Hopper Assembly	1
3	80472	Blower, Distribution	1
4	88106	Gasket, Distribution Blower	1
5	69763	Weldment-Exhaust Duct	1
6	88100	Gasket, Exhaust Blower	1
7	80473	Blower, Exhaust	1
8	69663	Damper Assembly	1
9	80461	Power Supply Cord	1
10	80610	Thermodisc, Surf Mt, Low Limit Pof	1
11	80609	Thermodisc, Surface Mount, 210°	1
12	80462	Receptacle, 3 Prong	1
13	80549	Pressure Switch	1
14	86668	Damper Rod	1
15	891121	Hose, Silicone (1/4" I.D. 450 DE)	1
16	80607	Ignitor	1
17	86633	Ignitor Tube	1
18	88117	Gasket, Exhaust Duct	1
19	88119	Insulation, Blanket	1
20	88118	Gasket, Ignitor Flange	1
21	88168	Gasket, Burnpot Housing	1
22	891148	Handle, Plastic	1
23	69703	Wldmt, Top Lid	1
24	80684	Control Plate	1
25	27763	Cowl	1
26	25868	Side,Left Cabinet	1
27	25488	Side,Right Cabinet	1
28	69762	Burnpot Assembly	1
29	69693	Weldment, Burnpot Housing	1
30	25497	Cleanout, Ash	2
31	69671	Ash Pan Assembly	1
32	891987	Plastic Knob	3
33	69846	Door Assembly	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer.
Use of third party components will void the warranty.

Parts Diagram



Key	Part No.	Description	Qty.
1	892002	Spring Handle, Brass, (.375)	1
2	86755	Door Handle	1
3	69901	Weld., Door Trim_1/2 Oval	1
4	40579	Cast Door, 1/2 Oval (C-D-018)	1
5	88082	3/4 Round Rope Gasket-Blk	4.3ft
6	88174	1/8 X 1 Window Gasket w/Adhesive	3ft
7	891979	Door Glass	1
8	25905	Air Wash Plate	1
9	25904	Clip, Glass	3

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer.
Use of third party components will void the warranty.