


4027 & ASA7

Repair Parts



MODEL 4027 & ASA7 - PARTS LIST

KEY	PARTNO.	DESCRIPTION	QTY.
1	40422	Cast Iron Legs	4
•	83507	3/8-16 x 1-1/4 Bolt	4
2	25096	Flue Collar	1
•	83431	Weld Tab	3
•	83045A	Washer 3/8 i.d. 7/8 o.d.	3
•	83432	5/16-18 x 1-1/2 Hex Bolt	3
3	25080B	Door Latch	2
•	83508	5/16- 18 x 3/4 Bolt	2
•	83338	5/16- 18 Lock Nut	2
4	69338B	Shaker Handle Assembly	12
*	40423	Complete Shaker Grate Assembly	1
5	83109	1/4-20 Square Nut	2
6	25079	Retainer, Cog	1
7	83227	1/4-20 x 1 Bolt	2
8	40408	Left Shaker Grate	1
9	40409	Right Shaker Grate	1
10	40407	Shaker Frame	1
11	40415	Cog, Grate	2
12	89066	Fire Brick (4-1/2 x 9 x 1-1/4 THK.)	12
13	69349	Ash Pan Assembly	1
14	25095	Ash Door - Painted	1
15	40437	Door Handle	2
16	83506	3/8 x 1-1/4 Roll Pin	2
17	40379	Draft Cap	1
18	83503	3/8-16 x 2-1/2 Carriage Bolt	1
19	83274	3/8-16 Lock Nut	1
20	83443	Door Pin	4
21	25094	Feed Door - Painted	1
22	891053	Door Glass	1
•	891067	Door Glass w/ Ashley Logo (For Model ASA7)	1
•	88087	Glass Gasket	2.5 ft
•	88066	5/8" Rope Gasket	3.375 ft
23	25178B	Top Glass Retainer	1
24	25179B	Bottom Glass Retainer	1
25	25180B	Side Glass Retainer	2
•	83202	10-24 x 3/8 Machine Screw	8
26	88057	1/2" Rope Gasket	4.5 ft
•	89574	Spring Handle	3
• - Not Shown			