


# Repair Parts



| Key | Part No. | Description                                  | Qty.  |
|-----|----------|----------------------------------------------|-------|
| 1   | 69660    | Complete Door Assembly                       | 1     |
| 2   | 88066    | 5/8" Rope Gasket                             | 6 ft. |
| 3   | 891813   | Door Glass                                   | 1     |
| 4   | 88174    | Gasket-Flat, Glass (3/16T x 3/8W)            | 6 ft. |
| 5   | 25465    | Glass Retainers                              | 2     |
| 6   | 83202    | Machine Screw - 10-24 x 3/8 Ph Hd.           | 4     |
| 7   | 83278    | Washer - 7/32 ID X 1/2 OD                    | 4     |
| 8   | 891373   | Hinge Pad                                    | 2     |
| 9   | 25080    | Door Latch (Uses 83508 - 5/16-18 x 3/4 bolt) | 1     |
| 10  | 89066    | Firebrick (4.5 x 9)                          | 9     |
| 11  | 891989-1 | Firebrick (3.33 x 9)                         | 6     |
| 12  | 891414   | Firebrick (2.25 x 9)                         | 1     |
| 13  | 891989-2 | Firebrick (1.25 x 2.25)                      | 1     |
| 14  | 86669    | Tube #1, Secondary Comb.                     | 2     |
| 15  | 86670    | Tube #2, Secondary Comb.                     | 1     |

| Key | Part No.            | Description                       | Qty. |
|-----|---------------------|-----------------------------------|------|
| 16  | 891990              | Retainer, Tube                    | 3    |
| 17  | 88158               | Fiber Board, Front                | 1    |
| 18  | 88159               | Fiber Board, Rear                 | 1    |
| 19  | 88160               | Fiber Blanket                     | 1    |
| 20  | 80598               | Blower Assembly                   | 1    |
| 21  | TK004<br>(optional) | Surround, Top                     | 1    |
| 22  |                     | Surround, Left Side               | 1    |
| 23  |                     | Surround, Right Side              | 1    |
| 24  |                     | Spring                            | 2    |
| 25  |                     | Trim-R, Surround                  | 1    |
| 26  |                     | Trim-L, Surround                  | 1    |
| 27  |                     | Trim-Top_L, Surround              | 1    |
| 28  |                     | Trim-Top_R, Surround              | 1    |
| 29  |                     | Key, Straight                     | 1    |
| 30  |                     | Key, Blank Straight               | 1    |
| 31  |                     | Key, Blank Corner (Can Use 89420) | 2    |
| 32  |                     | Key, Corner (Can Use 89419)       | 2    |

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer.  
Use of third party components will void the warranty.