

PARTS LIST – PB65XL RAILROAD POTBELLY STOVE

When ordering missing or replacement parts, always give the **Model Number** of the stove, **Part Number**, and **Part Description**. Use the illustrations and part lists provided to identify parts.

Part No.	Description	Qty.	Part No.	Description	Qty.
1	Cook Lid	1	12	Shaker Grate	1
2	Lid Lifter.....	1	13	Lower Chamber	1
3	Collar Top.....	1	14	Base	1
4	Top Plate.....	1	15	Leg.....	4
5	Upper Chamber.....	1	16	Ash Door.....	1
6	Feed Chamber.....	1	17	Slide Draft.....	1
7	Feed Door.....	1	18	Slide Draft Knob	1
8	Spin Draft.....	1	19	Ash Drawer.....	1
9	Spring Handle.....	1	20	Draft Damper (for pipe installation).....	1
10	Burn Chamber	1	21	Hardware Pack (not shown).....	1
11	Shaker Door.....	1			

