


Parts Diagram



Parts List

KEY	PART NO.	DESCRIPTION	QTY.
1	40809	Flue Collar	1
2	40789	Top, Cast Iron	1
3	88257	3/8" Top Rope Gasket	6.5 ft
4	88256	Kao Wool	1
5	27737	Top Heat Shield	1
6	40788	Back, Cast Iron	1
7	88257	3/8" Back Rope Gasket	5 ft
8	40786	Side, Cast Iron	2
9	892651	Tube Assembly	1
10	88257	3/8" Bottom Rope Gasket	5.5 ft
11	40782	Bottom, Cast Iron	1
12	27735	Inner Heat Shield	1
13	27736	Outer Heat Shield	1
14	40790	Leg	4
15	89975	Handle Bracket	1
16	88257	3/8" Front Rope Gasket	5ft
17	40783	Front, Cast Iron	1
18	40787	Hearth, Cast Iron	1
19	892652	Air Intake Box	1
20	88174	Gasket - Flat, Glass (3/16T x 3/8W)	11 in
21	88257	3/8" Door Rope Gasket	2.5 ft
22	40785	Door, Cast Iron	1
23	89975	Handle Extension	1
24	891135	Handle, Spring (Lg-Nickel)	1

CAUTION:

Never alter the damper slide or the adjustment range to increase FIRING ring for any reason. Doing so could result in heater damage and will void your warranty.