




Repair Parts



Key	Part No.	Description	Qty.
1	69427	Ash Pan	1
2	40292	Flue Collar	1
3	891492	Blower Assembly (B36)	1
4	25300	Blower Housing	1
5	25305	Deflector, Air	1



Key	Part No.	Description	Qty.
1	89066	Firebrick (4-1/2 X 9)	15
2	69458	Plug, Ash	1
3	24103	Firebrick, Half (4-1/2 X 4-1/2)	2
4	86645	Tube (Ø7/32), Secondary Air	1
5	88250	Board, Ceramic Fiber	2



Key	Part No.	Description	Qty.
1	891135	Spring Handle (LG Nickel)	1
2	891084	Handle Rod	1
3	891112	Feed Door	1
4	891108	Glass w/King Logo	1
5	88087	Door Glass Gasket	1
6	891114	Top/Side Window Bracket	4
7	891115	Bottom Window Bracket	1
8	891113	Feed Door Gasket	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.