




Replacement Parts




Ring, Flue Collar	
22761	1




Flue Collar, 6" C.I.	
40246	1




Gasket, Flue Collar	
88032	1




Stub Collar 8"	
891214	2




Handle Assembly	
891098	1




Assembly, Ash Door	
610496	1




Ashpan Weldment	
610498	1




Wooden Knob Assembly	
892767	3




Firebrick (4.5 X 9) Pumice	
89066	19




Cast Grate	
40605	1




Curtain, Smoke	
23800	1




Shaker Grate Tool	
610744	1




Assy, Blower/T'stat Brkt.	
68234	1



Fan Cntrl Cord Assy	
68231	2




4 X 4 Junction Box	
80131	1




Supply Cord	
80232	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.

Replacement Parts




Control Mounting Bracket	
22140	1




T-Disc (200-20°F)	
80789	1




Actuator Conduit Assy.	
610850	1




Cabinet Back	
27883	1




Cabinet Top	
25562	1




Left Cabinet Side	
25467	1




Locking Mech, Feed Door	
891097	1




Feed Door Hinge Bracket	
22662	1




Hinge Spacer	
24232	1




Firebrick 4-1/2 X 7-1/2	
892945	1




Feed Door Assy.	
68217	1




Tertiary Damper Assy.	
610499	1




Tertiary Damper Shield	
27909	1



Handle, Spring	
891135	2




Secondary Damper Shield	
27908	1




Secondary Damper Assy.	
610500	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.


Replacement Parts




Wooden Handle	
89520	1



Board, Ceramic Fiber	
892726	2




Secondary Tube	
86870	6



Brick Retainer	
27879	2




Right Shoulder	
28015	1




Front Liner	
27937	1




Left Shoulder	
28016	1




Blower Gasket	
89319	2




Blower Assembly	
80594	2




Cable Clamp	
83785	1




Wire Guide	
28746	1




Slide Plate Assembly	
610750	1




Back Plate Assembly	
610751	1



Cover Weldment	
610752	1




Transformer, Fan Center	
80130	1




Filter Box, Side Panel	
28706	2

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.


Replacement Parts




Filter Box, Medium Panel	
28708	2




Upper Handle Bracket	
27924L	2




ADJ. 140°F Thermodisc	
80388	1




Left Heat Shield	
28789	1




Right Heat Shield	
28790	1




Right Cabinet Side	
28665	1



Servo Bracket	
28613	1




Motorized Draft Actuator	
80592	1




Servo Arm	
610745	1



Galvanized Steel Wire	
892951	1



Digital Wall Thermostat	
80779	1



16 AWG Red Wire	
610745	2

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.