




Parts List




Hearth Extension	
40771	1




Baffle	
892510	1




KAO Wool	
88228	1



6" Damper	
40398	1




Bottom Channel	
892508	1




Door Assembly	
892515	1




Rod	
892533	4




Leg	
40817	4




Handle Assembly	
892722	1



Main Top	
40774	1




Tube Weldment	
892516	1




3/8" Rope Joint Top	
88033	8.75 ft

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.


Parts List




Main Back	
40299	1




Door Frame	
40302	1




Main Bottom	
40772	1




Flue Collar	
40784	1



6" Damper Pivot Pin	
892517	1



Handle Bracket	
89975	1



Main Side	
40775	2

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.