




Key	Part #	Description	Qty
1	81212.2	Flex Tube	1
2	89761	Piezo Ignitor	1
3	81202	Control Valve (LP)	1
	81198	Control Valve (NAT)	1
4	81212-6	Bottom Burner	1
5	81212.8	On/Off Valve	1
6	81212.14	(Auto/Off/Auto) Switch	1
7	89921	Pilot Assembly (NAT)	1
	89922	Pilot Assembly (LP)	1
8	81212-11	Top Burner	1

9	81212.16	Upper Burner Orifices (Nat) #46	1
10	81212.20	Upper Burner Orifices (LP) #56	1
11	81212.17	Lower Burner Orifices (NAT) #48	1
12	81212.21	Lower Burner Orifices (LP) #55	1
13	80442	80 CFM Blower	1
14	80090	Rheostat W/Knob	1

⚠ WARNING: FAILURE TO POSITION THE PARTS IN ACCORDANCE WITH THESE DIAGRAMS OR FAILURE TO USE ONLY PARTS SPECIFICALLY APPROVED WITH THIS APPLIANCE MAY RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.