







Key	Part#	Description	Qty
1	891135	Handle, Spring (Lg-Nickel)	1
2	892854	Door Handle	1
3	AC09185	Roller Ball Kit	1
4	40793	Feed Door Frame	1
5	88066	5/8" Rope Gasket	4 ft
6	892686	Door Glass	1
7	88087	Window Gasket	2.5 ft
8	28220	Top Glass Brace	1
9	28221	Bottom Glass Brace	1
10	83709	Door Pin	2

Key	Part #	Description	Qty
1	892199	Housing, PCBA Controller	1
2	80630	PCBA, Controller	1
3	891148	Lid Latch	1
4	892669	Top Weldment	1
5	80491	Lid Switch	1
6	80631	PCBA	1
7	892674	Vented Back Panel	1
8	80462	AC Electrical Connector	1
9	80602	Exhaust Blower	1
10	88166	Gasket, Exhaust Blower	1
11	892668	Ash Clean-Out Covers	2
12	88258	Gasket, Ash Clean-out	2
13	80607	Igniter	1
14	83538	Shaft Collar - Ignitor Tube	1
15	69762	Burnpot	1
16	80599	T-Disc, Exhaust	1
17	80529	Auger Motor	1
18	892665	Auger Motor Mounting Bracket	1
19	892661	Auger Housing Weld.	1
20	892677	Auger	1
21	892664	Agitator Bushing	1
22	80455	T-Disc, Room Air	1
23	80709	Room Blower	1
24	80549	Vacuum Switch	1
25	88176	Insulation Blanket	1
26	892685	Hearth Plate	1
27	892682	Door Assembly	1
*	80710	Wiring Harness	1
*	80711	Thermistor	1
* Item Not Shown			

IN ORDER TO MAINTAIN WARRANTY, COMPONENTS MUST BE REPLACED USING ASHLEY PARTS PURCHASED THROUGH YOUR DEALER OR DIRECTLY FROM ASHLEY. USE OF THIRD PARTY COMPONENTS WILL VOID THE WARRANTY.