


Parts List Ashley AP5660PE



Parts List

Key	Part #	Description	Qty
1	891995	Magnet	4
2	891997	Latch, Ash Pan	2
3	891996	Ash Pan	1
4	88162	Glass w/Gasket, Side	2
5	88161	Glass w/Gasket, Center	1
6	891994	Burn Pot	1
7	88165	Brick Panel - Right	1
8	88163	Brick Panel - Center	1
9	88164	Brick Panel - Left	1
10	892037	Hearth Trim	1
11	69794	Exhaust Grill	1
12	891540	Latch, Door	4
13	80631	PCBA Board	1
14	80549	Pressure Switch	1
15	80601	Switch, Hi-Temp	1
16	80606	Motor, Auger	1
17	80604	Igniter	1
18	88167	Gasket, Convection Blower	1
19	80622	Blower, Convection	1
20	891999	Auger	1
21	891998	Bushing	2
22	88166	Gasket, Exhaust Blower	1
23	80602	Blower, Exhaust	1
24	80599	Switch, Low-Temp	1
25	80491	Micro Switch	1
26	892199	Housing, PCBA Controller	1
27	80676	PCB, Circuit Board	1
*	88082	Gasket, 3/4 Rope	6 ft
*	892064	Decorative Log	1
* Not Shown			

IN ORDER TO MAINTAIN WARRANTY, COMPONENTS MUST BE REPLACED USING ASHLEY PARTS PURCHASED THROUGH YOUR DEALER OR DIRECTLY FROM ASHLEY. USE OF THIRD PARTY COMPONENTS WILL VOID THE WARRANTY.