

Replacement Parts




Ref. No.	Part No.	Description	Qty
1	610556	Heat Shield Assembly	1
2	27992	Heat Shield	1
3	88265	Kao Wool Insulation	1
4	610560	Insulation Support Weldment	1
5	27896	Pedestal Rear	1
6	610559	Pedestal R.H. Side Weldment	1
7	610534	Pedestal Base Weldment	1
8	610557	Pedestal Front Weldment	1
9	610558	Pedestal L.H. Side Weldment	1
10	892757	Bottom Hearth Trim	1
11	27881	Ash Hole Cover	1
12	88111	Gasket, Agitator Bracket	1
13	27881	Ash Hole Cover	1
14	891135	Handle Coil	1
15	27999	Air Wash Cover	1
16	28000	Air Wash Slide Plate	1
17	892758	Top Hearth Trim	1
18	69976	Door Assembly	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.

Ref. No.	Part No.	Description	Qty
1	1B-01	Ceramic Fiber Pad	1
2	1B-02	C-Cast Fiberboard (9.3"x11"x0.5")	2
3	1B-03	Air Tube, Middle	2
4	1B-04	Air Tube, Front	1
5	892718	Firebrick M-2	2
6	892717	Firebrick A-1	12
7	892205	Firebrick B-1	1
8	892759	Firebrick U-2	1
9	892721	Firebrick U-1	1
10	892720	Firebrick V-2	2





Ref. No.	Part No.	Description	Qty
1	1B-16	Handle Assembly (complete)	1
2	1B-18	Door Frame	1
3	1B-19	Door Glass 891817	1
4	1B-20	Gasket, 3/8" Fiberglass Glass	1
5	1B-21	Retainer, Glass	5
6	1B-24	Gasket, Door	1
7	83922	Hinge Pin	2

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.