

Parts List / Repair Parts




Key	Part No.	Description	Qty.
1	26699	Cover Plate, Access Panel	1
2	88206	Access Panel Insulation	1
3	27493	B36 Air Deflector	1
4	27494	B-36 Mounting Plate	1
5	891492	Blower Assembly (B36)	1
6	26410	Tensioner, Damper Rod	2
7	26708	Damper Rod	1
8	892260	Trim, Stainless (21")	1
9	892334	10.00 X 3.50 Glass	2
10	26683	Window Cover	2
11	69953	Door Assembly	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.


Parts List / Repair Parts



Key	Part No.	Description	Qty.
1	891135	Handle, Spring (Lg-Nickel)	1
2	892333	4" Handle	1
3	40585	Large Viewing Glass Door	1
4	26314	Gasket Clamp	1
5	26312	Glass Clamp, Side	4
6	26311	Glass Clamp, Bottom	2
7	88174	Glass Gasket (1 x 1/8)	4.4ft
8	892204	Glass	1
9	88082	3/4 Round Rope Gasket-Blk	4.7ft



Wiring Schematic



Key	Part No.	Description	Qty.
1	88198	Ceramic Fiber Board Top	1
2	86726	Tube (Ø5/32) , Secondary Air	2
3	892422	Back Panel, Firebox	1
4	26706	Right Brick Retainer	1
5	89066	Firebrick (4-1/2 X 9)	5
6	891530	Firebrick (4.5 X 7.5 X 1.25)	2
7	27338	Firebrick (3 X 4-1/2)	3
8	26705	Left Brick Retainer	1
9	86727	Tube (Ø3/16) , Secondary Air	1

In order to maintain warranty, components must be replaced using original manufacturers parts purchased through your dealer or directly from the appliance manufacturer. Use of third party components will void the warranty.