

PARTS LIST FOR 1370

1	Base.	200137
2	Side Skirt.	200508
3	Back Panel.	205316
4	Left Panel.	207726
5	Right Panel	207811
6	Ash Pan Angle Guide	226101
7	Bracket	231300
8	Top Cover	252747
9	Stiffener	275608
10	Front Panel	600338
11	Rear Firebox Shell.	604902
12	Ash Pan	624027
13	Lower Front Panel	652547
<hr/>		
18	Ash Door Frame.	300450
19	Ash Door.	300812
20	Loading Door.	301028
21	Main Door Frame	301130
22	Door Latch.	301501
23	Manual Air Damper	301729
24	Top Plate	302157
25	Flue Collar	303820
26	Plate in Front of Door.	308505
27	Hood Grill.	308709
28	Tool.	312801
29	Door Latch lever.	861201
<hr/>		
34	Poker	415502
35	Snap Clip	100602
36	Roller Catch.	101050
37	Firebrick	105209
38	Firebrick	105211
39	Side Door Hinge	109814
40	Cover Hinge Assortment (Top Hinge Assembly).	109815
41	Name Plate.	122802
42	Trim.	123439
43	Push Clip	134501
44	Door Knob	158601
45	Sealing Rope.	181502
46	Ash Door Spring	166003
47	Ash Door Campin	100903