

1500HT/1500HTL

MODEL: 1500HT/1500HTL		
DESC. FREESTANDING, TOP VENT, 6" FLUE		
MODEL YRS: 1989-1997		
PART NBR	DESCRIPTION	REMARKS
	<b>DOOR PARTS</b>	
1.G6000	DOOR ASSEMBLY, GOLD	
1.G6000-1	DOOR FRAME W/GASKET	
1.86-128	DOOR GASKET KIT, 3/4 INCH ROPE	INCLUDES ADHESIVE
1.10580	GASKET, GLASS CHANNEL (PER FOOT)	REQUIRES 5'
1.G2000-7	GLASS, ARCHED (9 1/2 X 15 3/4)	●
1.10300	HANDLE ASSEMBLY	GOLD DOOR
1.85-11	HANDLE, COIL SPRING	*SN > 5379
1.11529	HINGE, PIN 10 L 18	
1.00340	NUT, TOP LOCK 3/8-16	TORQUE PLATE NUT
1.10362	TORQUE PLATE	LATCH
	<b>MODULE ASSEMBLY PARTS</b>	
1.12095	MODULE ASSEMBLY	
1.00907	MODULE CONTROL HANDLE	
	<b>COMPONENT PARTS</b>	
1.01100	ASH DRAWER	
1.11709	ASH DUMP ASSEMBLY	*SN < 6001
1.11811	ASH DUMP INSULATION	*SN < 6001
1.00715	BOLT, LEG	REQUIRES 1 PER LEG
1.01098	GASKET, ASH DRAWER	REQUIRES 2'
1.01135	KNOB, ASH DRAWER	
1.00950	LEG, CAST IRON	
1.13009	TRIM, TOP LOUVER	
	<b>FIREBOX PARTS (SEE BRICK DIAGRAM FOR BRICK PART NUMBERS)</b>	
1.12020	FRONT AIR TUBE ASSEMBLY	
1.01115	GRATE, CAST IRON	*SN > 6001
1.12030	REAR TUBE ASSEMBLY	
	<b>MISCELLANEOUS PARTS</b>	
1.1054	CERAWOOL PAD, FOR MARBLE	REQUIRES 1
1.1051	CERAWOOL STRIPS, FOR MARBLE	REQUIRES 4
1.14440	DIAL-A-TEMP (RHEOSTAT)	
1.12086	INSTRUCTION MANUAL	
1.76-117B	NAMEPLATE	

\*SN Stove serial number range, parts are compatible with:  
 ">" = higher than # indicated, "<" = less than # indicated, "-" numbers within ra  
 ● Glass insulation is not included w/glass replacement