

## REPAIR PARTS LIST

### Models No. 1CWC & No. 2CWC

| Key No. | Part No.   |            | Description                                 |
|---------|------------|------------|---|
|         | 1CWC       | 2CWC       |   |
| 1       | 010-0358   | 010-0381   | Main Body                                   |
| 2       | 001-0219-2 | 010-0219-2 | Shaker Tool                                 |
| 3       | 061-0697   | 061-0697   | Load Door                                   |
| 4       | 061-0149   | 061-0149   | Rivet, Hinge, Load Door (2 required)        |
| 5       | 001-0637   | 001-0637   | Picket (2 required)                         |
| 6       | 061-0178   | 061-0178   | Picket Holder (2 required)                  |
| 7       | 080-0644   | 080-0644   | Nut, Hex, #8-32 (4 required)                |
| 8       | 090-0719   | 080-0719   | Gasket Kit, Load Door                       |
| 9       | 061-0150-2 | 061-0150-2 | Spring, Handle                              |
| 10      | 061-0635-2 | 061-0635-2 | Cap, Handle                                 |
| 11      | 090-0718   | 090-0718   | Glass & Frame Assembly                      |
| 12A     | 080-0645   | 080-0645   | Washer, #8, Standard .032 (4 required)      |
| 12B     | 080-1034   | 080-1034   | Washer, #8, Special .048 (4 required)       |
| 13      | 061-0140   | 061-0140   | Ash Door                                    |
| 14      | 061-0179   | 061-0179   | Slider Ass'y, Ash Door                      |
| 15      | 090-0719   | 090-0719   | Gasket Kit, Ash Door                        |
| 16      | 061-0636-2 | 061-0636-2 | Cap, Handle                                 |
| 17      | 061-0151-2 | 061-0151-2 | Spring, Handle                              |
| 18      | 001-1878   | 001-1878   | Adjustment Knob Assembly                    |
| 20      | 061-0159   | 061-0159   | Indicator                                   |
| 21      | 001-0217   | 001-0217   | Ash Pan                                     |
| 22      | 001-0218-2 | 001-0218-2 | Handy Tool                                  |
| 23      | 071-0183   | 071-0183   | Shaker Grate (2 required)                   |
| 24      | 071-0189   | 071-0187   | Linkage Rod                                 |
| 25      | 071-0357   | 071-0188   | Pivot Assembly                              |
| 26      | 080-0647   | 080-0647   | Nut, Spring, Push-on .312 dia. (3 required) |
| 27A     | 001-0643   | —          | Brick, Rear (5 required)                    |
| 27B     | —          | 001-0200   | Brick, Rear (2 required)                    |
| 28      | 001-0362   | 001-0201   | Brick, Left side                            |
| 29      | 001-0363   | 001-0201   | Brick, Right side                           |
| 30      | 001-0364   | 001-0384   | Brick, Left front                           |
| 31      | 001-0365   | 001-0384   | Brick, Right front                          |
| 32      | 001-0680   | 001-0216   | Baffle                                      |
| 33      | 080-0648   | 080-0648   | Screw, Sheet Metal, #6 (2 required)         |
| 34      | 090-0722   | 090-0722   | Thermostat Housing & Wire Assembly          |
| 35      | 080-0649   | 080-0649   | Carriage Bolt, #10-24 x 3/4 (4 required)    |
| 36      | 080-0650   | 080-0650   | Nut, Spring, #10-24 x 3/4 (4 required)      |
| 37      | 090-0749   | 090-0749   | Gasket, Blower                              |
| 38      | 090-1037   | 090-1037   | Blower Assembly                             |
| 39      | 080-0651   | 080-0651   | Nut, Hex, #10-24 (4 required)               |
| 40      | 080-0662   | 080-0662   | Screw, Flathead #10-24 x 3/4 (2 required)   |
| 41      | 080-0651   | 080-0651   | Nut, Hex, #10-24 (2 required)               |
| 45      | —          | 001-0212   | Side Brick Support (2 required)             |