

England Stove Works 25-PI 55-SHP20 and 55-TRP20 Parts List 2004 and After

AC-GGK	Glass Gasket Kit (gasket only, no glass)
AC-DGKC	Door Gasket Kit (#2 on diagram)
AC-114	Brass Louvers (#26 on diagram) (2001 and later Models; for earlier models call 800-245-6489 for AC-112 louvers)
AC-114BN	Nickel Louvers (#26 on diagram)
AC-G9	9" x 9" Glass <i>with</i> Gasket (#3 on diagram)
AC-SH	Brass Door Spring Handle
AC-SHN	Nickel Door Spring Handle
AC-MCSP	Hi-Temperature Charcoal Paint
AC-MBSP	Hi-Temperature Black Paint
PU-MS	Auger Motor Support Shelf
PU-047040	1 RPM Auger Motor Assembly (#18 on diagram)
PU-BP02A	Burn Pot Assembly (#'s 5 and 11 on diagram, call if you need only one part of this 2-piece assembly)
PU-076002B	Combustion (Exhaust) Blower (includes 3" adapter) (#'s 8 and 9 on diagram)
PU-4C447	Convection (Room Air) Blower (#13 on diagram) (2002 and later Models; for earlier models order PU-4C442)
PU-AF6T	Top Auger Shaft (#14 on diagram)
PU-AF11B	Bottom Auger Shaft (#14 on diagram) (2001 and later Models; for earlier models call for assistance)
PU-HL-PI	Hopper lid for Insert model) (#25 on diagram)
PU-UCF204-12	Auger Bearing (#16 on diagram)
PU-2X570	$\frac{3}{4}$ " Locking Collar (#17 on diagram)
PU-CB04	Digital Control Board (#12 on diagram)
PU-VS	Vacuum Shut-Down Switch (see Control Board diagram)
CU-VS	Second Vacuum Switch (see Control Board diagram)
PU-CBG	Combustion Blower Gasket (#10 on diagram)
PU-CMG	Combustion Motor Gasket
PU-BPG	Burn Pot Gasket (#6 on diagram)
PU-ABGN	Auger Bearing Gasket (#15 on diagram)
PU-HLG	Hopper Lid Gasket (#22 on diagram)
PU-CHA	Cartridge Heater (Igniter) Assembly (#27 on diagram)
PU-CBF6	6 AMP Control Board Fuse

OPTIONS:

GU-1E30-914	Wall Thermostat
AC-103	Brass Lip Trim for Ash Apron (2001 and later Models; for earlier models, order Part # AC-101-PU.)
AC-103BN	Brushed Nickel Lip Trim for Ash Apron
AC-104	Brass Lip & Backplate Trim
AC-106-P/SH-106-P	Brass Window Trim
AC-106-PBN	Brushed Nickel Window Trim
AC-AV	Loveless Ash Vacuum
AC-AVT	Ash Vacuum Tool Kit

NUMBER PART DESCRIPTION

- 1. Door (part# CA-19A)
- 2. Door Gasket (part# AC-DGKC)
- 3. Glass with gasket (part# AC-G9)
- 4. Impingement Plate (Baffle) (part# PU-5206-10)
- 5. Burn Pot (part# PU-BP02A)
- 5a. Wear Plate for Burn Pot (part# PU-BP98WPA)
- 6. Burn Pot Gasket (part# PU-BPG)
- 7. Side access Panel (part# PU-5526)
- 8. Combustion Blower (part# PU-076002B)
- 9. 3" Blower Adapter (part# CA-1598)
NOTE: part# 9 comes with part#8
- 10. Combustion Blower Gasket (part# PU-CBG)
- 11. Pellet Feeder Pot (part# CA-FS04)
- 12. Digital Control Board (part# PU-CB04)
- 13. Convection(room air) Blower (part# PU-4C447)
- 14. Augers (part# top PU-AF6T, bottom PU-AF11B)
- 15. Block Bearing Gaskets (2ea) (part# PU-ABGN)
- 16. Block Bearings (2ea) (part# PU-UCF204-12)
- 17. 3/4" i.d. Shaft Collar (2EA) (PART# PU-2X750)
- 18. Auger Motors (2ea) (part# PU-047040)
- 19. Rear Access Panel (part# PU-5525)
- 20. Hopper Flange Gasket (part# PU-HFG)
- 21. Hopper
- 22. Hopper lid Gasket (part# PU-HLG)
- 23. Hopper Top
- 24. Vacuum Shutdown Switches (part# PU-VS , PU-VSA)
Vacuum Hose (part# PU-VH)
- 25. Hopper Lid (part# PU-HL-PI)
- 26. Brass Louvers (2ea) (part# AC-114)
- 27. Cartridge Heater (igniter) (part# PU-CH)

