

# Hitzer

## 254 Freestanding Stove

### Replacement Parts

<b>Grate Parts</b>	
254g	Front Grate
254g/ext	Rear Grate
254gf	Grate Frame
254gshc	Grate Shaker Handle with Spring
254s	Grate Shaker Spring Pewter or Gold
254gc	Grate Connector
<b>Firebrick Parts</b>	
fb49	Firebrick 4x9 (10 needed)
fb1/3	Firebrick 1/3 x9 (1 needed)
254fbr	Firebrick Retainer
<b>Ash Door Parts</b>	
254adc	Ash Door Complete
254ads	Ash Door Draft Slide
1/2gasket	Ash Door Gasket 1/2" (5' required)
254ads	Ash Door Spring Handle
254ap	Ash Pan
254al	Ash lip
254rk	Draft Slide Rosette Knob (Gold or Pewter)
<b>Blower Parts</b>	
254134blow	Blower 134CFM
8'cord	8' Power Cord
vsc	Variable Speed Control
<b>Baffle Plate/Damper Parts</b>	
254bp	Baffle plate
254dhs	Damper handle Spring
254damp	Sliding damper
<b>Door Parts</b>	
3/4gasket	Fuel Door Gasket 3/4" (5.5' required)
254dc	Door Complete (Glass, Gasket, Handle)
254gdc	Gold Door Complete
254pdc	Pewter Door Complete
254dh	Door Handle w/Spring
254sdh	Single Door Handle
254dl	Door Latch w/Roller
<b>Glass Parts</b>	
254glass	Fuel Door Glass w/Gasket
254ggasket	Glass Gasketing (4.5' required)
254screw	Screws for Glass (6 required)

254plate	Steel Plate for Door (Used in place of glass)
<b>Thermostat Parts</b>	
254tc	Thermostat Complete
254tms	Thermostat Bi-Metal Spring
254tk	Thermostat Knob and Spring
254aid	Air Intake Door and Chain
254aih	Air Intake Door Hinge
254mc	Air Intake Magnetic Catch
254conn	Chain Connector
<b>Trim Parts</b>	
254accent	Gold or Pewter Trim Kits