

## PART DESCRIPTION

10087	-	Brick 4½" x 9" 9	27062	-	Baffle Insulation Rear
14200	-	Damper Knob	27063	-	Baffle Insulation Front
14222	-	Blower Switch Ext.	27064	-	Insulation - Back
14224	-	Switch Knob	27065	-	Insulation ½ Bottom
14248	-	Handle c/w Nut	27067	-	Insulation Sides
14249	-	Spring Handle	27075	-	Face Plate
14250	-	Door Latch	27102	-	Decorative Arch Black
17064	-	Thermostat	27103	-	Decorative Arch Brown
17067	-	Trim Frame Assembly Complete	27104	-	Decorative Arch Gold
17092	-	Angle Bracket and Screws	27106	-	Window Decorations Black - PR.
17094	-	Trim Ass'y Right Side	27107	-	Window Decorations Brown - PR.
17096	-	Trim Ass'y Left Side	27108	-	Window Decorations Gold - PR.
17098	-	Trim Ass'y Top	27109	-	Ash Catch Assembly
17220	-	Blower with Switch	90102	-	Door frame - Black with liner
27081	-	Brick 4½" x 8" 2	90103	-	Door Frame - Gold with Liner
27083	-	Brick angled - 2			
27009	-	Front Plate			
27012	-	Ash Lip Assembly			

Woodsman's Parts Plus .com