

# Hitzer

## 30-95 Freestanding Stove

### Replacement Parts

<b>Grate Parts</b>		
30grate	Grate	
30gf	Grate Frame	
30gsh	Grate Shaker Handle w/Spring	Gold/Pewter
30gss	Grate Shaker Spring	Gold/Pewter
<b>Firebrick Parts</b>		
fb49	Firebrick 4x9	(12 required)
fb1/3	Firebrick 1/3x9	(1 required)
<b>Ash Door Parts</b>		
30adc	Ash door complete	
30ads	Ash door draft slide	
1/2gasket	Ash door gasket 1/2"	(5ft required)
30al	Ash Lip	
30ads	Ash door spring handle	
30ap	Ash Pan	
30rk	Draft slide rosette knob	
<b>Blower Parts</b>		
30134blower	Blower 134CFM	
vsc	Variable Speed Control	
8'cord	8' power cord	
<b>Door Parts</b>		
3/4gasket	Fuel Door Gasket 3/4"	(5.5' required)
30dc	Door Complete	Includes: Door, Gaskets, Glass, Handle
30gdc	Gold Door Complete	
30pdc	Pewter Door Complete	
30s	Door Handle Spring	
30sdh	Single Door Handle	
30dl	Door Latch w/roller	
<b>Glass Parts</b>		
30glass	Fuel Door Glass w/Gasket	
30plate	Steel Plate for Door	Used In Place of Glass
30ggasket	Glass Gasket	(4.5' required)
30gr	Glass Retainer	(2 required)
30screw	Screws for Glass	(6 required)
<b>Thermostat Parts</b>		
30tc	Thermostat Complete	
30tms	Thermostat Bi-Metal Spring	
30tk	Thermostat Knob and Spring	

30aid	Air Intake Door and Chain	
30conn	Chain conector	
30aih	Air Intake Door Hinge	
30mc	Air Intake Door Magnetic Catch	
<b>Hopper Parts</b>		
1 1/2gasket	Old Style Lid Gasket (1-1/2")	(4' required)
1/2gasket	Cast Hopper Lid Gasket 1/2"	(4' required)
30hlc	Hopper Lid Complete (Old Style)	
30hlcc	Hopper Lid Complete (Cast)	
30hll	Hopper Lid Latch	
30hlift	Hopper Lid Lifter with Spring	
30rhopper	Removable Hopper	
30eye	Eye Bolt	
<b>Decorative Hood Parts</b>		
30knob	Knob for Hood	
30hc	Hood Complete	
<b>Trim Kits</b>		
30accent kit	Gold or Pewter Accent Kit:	
	ash door handle spring, rosette knob, shaker handle spring, fuel door handle spring, lid lifter spring, knob on hood	