

AUTOMATIC WOOD BURNING CIRCULATOR - MODEL 3021

KEY NO	PART NO	DESCRIPTION	QTY
1	67739	CABINET TOP	1
2	86192	THERM LINKAGE	1
3	67743	THERM ASSY	1
4	67514	CABINET BACK	1
5	67741	CABINET DOOR FRAME	1
6	89065	DOOR HINGE	4
7	67742	CABINET TOP	1
8	89173	DOOR HANDLE	1
9	83210	SET SCREW	1
10	89041	SPRING	1
11	67724	DOOR LATCH	1
12	86191	THERM LINK ADJUST	1
13	67725	CABINET FRONT	1
14	85329	CONTROL PANEL PLATE	1
15	89172	THERM KNOB	1
16	67740	CABINET LEFT END	1
17	21593	HINGE SUPPORT	1
18	83833	HINGE CLIP	1

AUTOMATIC WOOD BURNING CIRCULATOR - MODEL 3021

KEY NO	PART NO	DESCRIPTION	QTY
1	21887	SHIELD, HEAT	1
2	17200	PIN, DRAFT DAMP HINGE	1
3	40075	FRAME, DRAFT DAMPER	1
4	67664	BASE	1
5	67668	DAMPER, DRAFT CONT	1
6	83818	CLIP	3
7	40055	GRATE, FIRE	2
8	21831	BAFFLE, THERMOSTAT	1
9	89066	FIREBRICK	10
10	67665	FIREBOX	1
11	21828	SPACER, FIREBRICK	1
12	66080	GRATE & LINER SUPPT	2
13	17350	RETAIN, TOP FIREBRK	2
14	88051	GASKET, FLUE COLLAR	1
15	67672	FLUE COLLAR ASSY	1
16	21548	SMOKE CURTAIN	1
17	17210	PIN, SMOKE CURT HINGE	1
18	83107	1/4-20X1 MACH SCREW	1
19	83177	RIVET	4
20	21842	ARM, CONT ROD	1
21	83072	1/4-20 NUT	1
22	83002	LOCKWASHER	1
23	67687	DAMPER. FEED DOOR	1
24	21834	DOOR FEED	1
25	LK-26	DOOR LATCH KIT	1
26	67567	HANDLE, WOOD	2
27	21804	GASK, ROPE FEED DOOR	1
28	67368	DOOR ASH(INC HAND/GASK)	1
29	83819	CLIP	4
30	21803	GASKET, ROPE ASH DOOR	1
31	21830	RETAIN FIREBRK TOP	2
32	67444	PAN, ASH	1
33	17120	LINER	1