

Hitzer

354 Freestanding Stove

Replacement Parts

Grate Parts	
354g	Front Grate
354gext	Rear Grate
354gf	Grate Frame
354gsc	Grate Shaker Handle with Spring (Gold or Pewter)
354s	Spring for Grate Shaker Handle (Gold or Pewter)
354gc	Grate Connector
Firebrick Parts	
fb49	Firebrick 4x9 (12 needed)
fb4x13	Firebrick 4 x13 (2 needed)
354fbr	Firebrick Retainer
Ash Door Parts	
354adc	Ash Door Complete
354adds	Ash Door Draft Slide
1/2gasket	Ash Door Gasket 1/2" (6 ft required)
354ads	Ash Door Spring Handle
354ap	Ash Pan
354al	Ash Lip
354rk	Draft Slide Rosette Knob (Gold,Chrome)
Blower Parts	
354210fm	Blower 210CFM
8'cord	8' Power Cord
vsc	Variable Speed Control
Baffle Plate/Damper Parts	
354bp	Baffle Plate
354sd	Sliding Damper
Door Parts	
354trim	Decorative Trim Above Fuel Door
3/4gasket	Fuel Door Gasket 3/4" (5.5' required)
354sdc	Door Complete (Glass, Gasket, Handle)
354gdc	Gold Door Complete
354pdc	Pewter Door Complete
354s	Door Handle Spring
354sdh	Single Door Handle
354dl	Door Latch w/Roller
Glass Parts	
354glass	Fuel Door Glass w/Gasket
354ggasket	Glass Gasketing (5' required)
354gr	Glass Retainer for Single Door (2 required)

354screw	Screws for Glass
354ddglass	Glass for Double Door w/Gasket
354gretain	Glass Retainer for Double Doors (3 required)
354plate	Steel Plate for Door (Used in place of glass)
Thermostat Parts	
354tc	Thermostat Complete
354tms	Thermostat Bi-Metal Spring
354tk	Thermostat Knob and Spring
354aid	Air Intake Door and Chain
354aih	Air Intake Door Hinge
354mc	Air Intake Magnetic Catch
354cc	Chain Connector
Trim Parts	
354accent	Gold or Pewter Trim Kits (ash door handle spring, rosette knob shaker handle, spring fuel, door handle)