

## 360DVS Series

Ref.	Description	360DVS2	360DVS3	360DVSL	360DVSR
1.	Log Set (complete)	10006350	10006350	10006350	10006350
1a.	Log - Rear (B120)	10006315	10006315	10006315	10006315
1b.	Log - Front Left (B121)	10006316	10006316	10006316	10006316
1c.	Log - Front Right (B122)	10006317	10006317	10006317	10006317
1d.	Log - Rear Left (B123)	10006318	10006318	10006318	10006318
1e.	Log - Bottom Left (B124)	10006319	10006319	10006319	10006319
1f.	Log - Rear Right (B125)	10006320	10006320	10006320	10006320
1g.	Log - Center Right (B126)	10006321	10006321	10006321	10006321
2.	Grate Assembly	10006014	10006014	10006014	10006014
3a.	Burner Housing Assembly, Nat.	10006148	10006148	10006148	10006148
3b.	Burner Housing Assembly, Prop.	10006299	10006299	10006299	10006299
*	Ceramic Burner Tile	10002165	10002165	10002165	10002165
*	Orifice/s, Main burner (Nat.)	Refer to the rating plate for specific orifice information			
*	Orifice/s, Main Burner (Prop.)	Refer to the rating plate for specific orifice information			
4a.	Pilot assembly PSE (Nat.)	10001741	10001741	10001741	10001741
4b.	Pilot assembly PSE (Prop.)	10001742	10001742	10001742	10001742
5a.	Pilot assembly SIT Top Conv. (Nat.)	10002264	10002264	10002264	10002264
5b.	Pilot assembly SIT Top Conv. (Prop.)	10002265	10002265	10002265	10002265
6.	Pilot, PSE (with cable & electrode)	10001824	10001824	10001824	10001824
7.	Pilot SIT Top Convertible	10002266	10002266	10002266	10002266
8.	Pilot Hood, SIT Top Convertible	10002385	10002385	10002385	10002385
*	Orifice, Pilot PSE (Nat.)	10001822	10001822	10001822	10001822
*	Orifice, Pilot PSE (Prop.)	10001823	10001823	10001823	10001823
*	Orifice, Pilot SIT Top convertible (Nat.)	10002268	10002268	10002268	10002268
*	Orifice, Pilot SIT Top conv. (Prop.)	10002269	10002269	10002269	10002269
*	Pilot tube & fittings (Top convertible)	10001296	10001296	10001296	10001296
*	Manifold tube & fittings	10002492	10002492	10002492	10002492
*	Flexible Gas Line (18") with fittings	20002500	20002500	20002500	20002500
9.	Thermocouple, PSE	10001828	10001828	10001828	10001828
10.	Thermocouple, SIT Top Convertible	53373	53373	53373	53373
11.	Thermopile	51827	51827	51827	51827
12.	Ignitor electrode (with cable), SIT	10001297	10001297	10001297	10001297
13.	Ignitor (Piezo), SIT 820 valve	52464	52464	52464	52464
14.	Ignitor (Piezo), Honeywell Valve	20000062	20000062	20000062	20000062
15a.	Valve, SIT 820 (Nat.)	52677	52677	52677	52677
15b.	Valve, SIT 820 (Prop.)	52678	52678	52678	52678
16a.	Valve, Honeywell (Nat.)	10001782	10001782	10001782	10001782
16b.	Valve, Honeywell (Prop.)	10001759	10001759	10001759	10001759
17.	Fan & Bracket FK12 (optional)	ZA1110	ZA1110	ZA1110	ZA1110
18.	Fan & Bracket FK24 (optional)	54103	54103	54103	54103
*	Temperature Sensor (optional)	51704	51704	51704	51704
*	Fan Speed Control (optional)	51738	51738	51738	51738
*	Fan Speed Control Knob (optional)	51882	51882	51882	51882
*	Electric Cord	51865	51865	51865	51865
19.	Remote ON/OFF switch (RN/RP models)	51842	51842	51842	51842
*	Wiring Harness (remote switch)	55923	55923	55923	55923
*	Remote ON/OFF Switch Kit (incl. bracket)	53875	53875	53875	53875
20.	Louvre Assembly, side top.	10000039	10000039	10000039	10000039

21.	Louvre Assembly, side bottom	10000040	10000040	10000040	10000040
22.	Louvre Assembly, end top	N/A	10002411	10002411	10002411
23.	Louvre Assembly, end bottom	N/A	10002412	10002412	10002412
24.	Hinge, lower louvre assemblies	52356	52356	52356	52356
25.	Trim Window Top/Bottom w/Magnets PB	57483	57483	57483	57483
26.	Trim Window Top/Bottom w/Magnets PB	n/a	10006197	10006197	10006197
*	Window Frame Assembly, side	10002483	10002483	10002483	10002483
*	Window Frame Assembly, end	N/A	10002484	10002484	10002484
*	Window Glass (complete with gasket), side	10002533	10002533	10002533	10002533
*	Window Glass (complete with gasket), end	N/A	10002534	10002534	10002534
*	Gasket Kit (glass replacement, 1x11' length)	57317	57317	57317	57317
27.	Window Frame Clamp	54174	54174	54174	54174
28.	Refractory Lining (vertical end walls)	10006254	10006254	10006254	10006254
29.	Refractory Lining (vertical side wall)	N/A	N/A	10006285	10006285
30.	CR Bottom Kit w/out Rear	10006257	10006257	10006257	10006257
*	Air Inlet Cover Plate Assembly	10006174	10006174	10006174	10006174
*	Air Inlet Cover Plate Gasket	10006171	10006171	10006174	10006171
*	Flue Pipe Plate Assembly	10002554	10002554	10002554	10002554
*	FluePipe Plate Gasket	10002237	10002237	10002237	1000223
*	Flue Cover Plate	10002298	10002298	10002298	10002298
*	Flue Cover Plate Gasket	10002233	10002233	10002233	10002233
*	Relief Plate (with gasket)	10002429	10002429	10002429	10002429
*	Deflector, Cabinet Top Short	N/A	10002260	10002260	10002260
*	Corner Post (left)	N/A	10006190	10006190	10006190
*	Corner Post (right)	N/A	10006191	10006191	10006191
*	Corner Post Mounting Bracket	N/A	10006195	10006195	10006195
*	Deflector Cabinet Top Long	54364	54364	54364	54364
31a.	Pilot Assembly SIT Top Convertible EN	10002387	10002387	10002387	10002387
31b.	Pilot Assembly SIT Top Convertible EP	10002388	10002388	10002388	10002388
32.	Ignitor Electrode SIT EN/EP	52465	52465	52465	52465
33.	Cable Ignitor SIT EN/EP	10000696	10000696	10000696	10000696
34a.	SIT822 Gas Control Valve EN	57884	57884	57884	57884
34b.	SIT822 Gas Control Valve EP	57883	57883	57883	57883
35.	Sensing Electrode (w/ Cable) EN/EP	57885	57885	57885	57885
36.	Transformer 24V EN/EP	7522409	7522409	7522409	7522409
37.	Ignition Module Honeywell EP	20000005	20000005	20000005	20000005
*	Wire Harness Honeywell EN/EP	10001979	10001979	10001979	10001979