

|    | <b>PART#</b> | <b>DESCRIPTION</b>        |
|----|--------------|---------------------------|
| 1  | C04523       | TV Screen                 |
| 2  | 68900        | TV Top                    |
| 3  | C95980       | Gold Trim Kit w/Hardware  |
| 4  | C04525       | Supports                  |
| 5  | C04527       | Rear Shield               |
| 6  | C04524       | Sides ( Interchangeable ) |
| 7  | C04526       | Brass Trim                |
| 8  | C45111       | Pedestal Assy.            |
| 9  | C27457       | Pan Head Screw            |
| 10 | C04535       | Pedstal Wrapper           |
| 11 | C04533       | Pedestal Base             |
| 12 | C04534       | Support Channel           |
| 13 | 83244        | Hex Nut                   |
| 14 | 83295        | Hex Nut - Blk.            |
| 15 | 83091        | Flat Washer               |
| 16 | 83244        | Hex Nut                   |
| 17 | C23255       | Square Head Screw         |
| 18 | 83437        | Tek Screw                 |