

Hitzer

503 Fireplace Insert

Replacement Parts

Grate Parts	
503g	Grate (2 Required)
503gf	Grate Frame
503gs	Grate Shaker
Firebrick Parts	
fb49	Firebrick 4x9 (14 needed)
fb1/3x9	Firebrick 1/3 x9 (2 needed)
Ash Door Parts	
503adc	Ash door complete
503adds	Ash door draft slide
1/2gasket	Ash door gasket 1/2" (4.5' required)
503ads	Ash door spring handle
503ap	Ash Pan
503rk	Draft slide rosette knob (Gold or Chrome)
Blower Parts	
503lbh	Left blower housing
503rbh	Right blower housing
503rb	Right blower
503lb	Left blower
8"cord	8' power cord
503wire	Blower wiring
503sdfc	Snap disc fan control
503 trim	Trim side air discharge Gold or Chrome (2 required)
503togs	Control toggle switch
Baffle Plate/Damper Parts	
503bp	Baffle plate
503ds	503 Damper Handle Spring
503damp	Sliding damper
Door Parts	
3/4gasket	Door Gasket 3/4" (5' required)
503dc	Single Door Complete (Glass, Gasket, Handle)
503gdc	Gold Door Complete
503pdc	Pewter Door Complete
503dl	Door Latch with Roller
503dhs	Door Handle Spring
503dh	Single Door Handle
Glass Parts	
503glass	Glass with Gasket

503gretain	Glass Retainers (2 required)	
503ggasket	Glass Gasketing (3.5' required)	
503screw	Screws for Glass	
Hopper Parts		
503hopper	Removeable Hopper	
503hlc	Hopper Lid Complete	
1/2gasket	Hopper Lid Gasket 1/2" (3.5' required)	
503lifter	Lid Lifter Handle Complete	
503lls	Lid Lifter Spring	
TRIM KIT		
503accent	Accent Kit	Ash Door Handle Spring, Rosette Knob, Fuel Door Spring, Damper Spring, Lid Lifter Spring, Side Air Discharge, Screws