

## CHECK CONDITION OF SHIPMENT

Upon receipt of this kit, check the condition of the packaging. Damage to the package should be noted on the carrier's freight receipt. Any damage claims as a result of shipping must be handled through the shipper. Travis Industries will provide assistance in resolving shipping claims or replacing items not included in the package. Please report any missing items immediately.

## COMPATIBILITY

- Answer
- Answer-95 (requires convection kit)
- Answer-NT (requires convection kit)

## ITEMS NEEDED FOR ASSEMBLY

- 5/16" nutdriver

## PACKING LIST

- Flue Adapter
- 4 10-24 x 1/2" Thread-Cutting Screws
- 1/2" Black Self-Adhesive Gasket (50" Long)
- Instruction Sheet

## INSTALLATION INSTRUCTIONS

The flue adapter is designed to make flue attachment easier for certain insert installations by moving the position of the flue exit.

1. Place the flue adapter over the flue exit on the insert. Mark the location of the four mounting holes on the top of the insert. Remove the flue adapter and drill four 5/32" holes into the top where the marks were placed (see the illustration below).
2. Place the flue adapter in place. Use a 5/16" nutdriver to attach the four screws that secure it to the insert.

