

American Hearth Loft See Through DLCX36 Part List

| INDEX NO.           | PART NO. | DESCRIPTION                      |
|---------------------|----------|----------------------------------|
| <b>COMMON PARTS</b> |          |                                  |
| 1                   | 17149    | TOP STANDOFF                     |
| 2                   | 28341    | TOP COVER                        |
| 3                   | R11053   | INSULATION, TOP WIDE             |
| 4                   | R11052   | INSULATION, TOP NARROW           |
| 5                   | R7566    | INLET VENT ADAPTOR               |
| 6                   | R7573    | INLET VENT GASKET                |
| 7                   | 17155    | FLUE OUTLET ASSEMBLY             |
| 8                   | M163     | GASKET, FLUE CONNECTOR           |
| 9                   | 29057    | SPRING RETAINER ASSEMBLY         |
| 10                  | 28990    | GLASS DOOR FRAME ASSEMBLY        |
| 11                  | 28688    | NAILING FLANGE                   |
| 12                  | R7571    | 3/8" ROMEX CONNECTOR             |
| 13                  | 27730    | JUNCTION BOX MOUNTING BRACKET    |
| 14                  | R3490    | JUNCTION BOX                     |
| 15                  | 28951    | BAFFLE, FLUE                     |
| 16                  | 26383    | BLOWER ASSY (RF FBB5-1)          |
| 17                  | 28946BL  | LINER SIDE, PORCELAIN            |
| 18                  | 28343BL  | BURNER COVER                     |
| 20                  | R9189    | GASKET, PILOT                    |
| 21                  | R11027   | TUBE BURNER                      |
| 23                  | R7624    | AIR SHUTTER                      |
| 24                  | R7575    | JAMB NUT                         |
| 25                  | 28332    | BURNER SUPPPORT, AIR SHUTTER END |
| 26                  | P212     | FITTING, ORIFICE                 |
| 27                  | 28331    | BURNER SUPPORT                   |
| 28                  | 28328    | BAFFLE, BURNER - MEDIUM          |
| 29                  | 28327    | BAFFLE, BURNER - LARGE           |
| 30                  | 28329    | BURNER BASE                      |

| INDEX NO.            | PART NO. | DESCRIPTION                          |
|----------------------|----------|--------------------------------------|
| 31                   | 11269    | GAS LINE BRACKET                     |
| 32                   | 26307    | VALVE BRACKET                        |
| 34                   | P239     | NIPPLE, 1 1/2"                       |
| 35                   | R10415   | VALVE, LP & NAT (AMERICAN FLAME)     |
| 36                   | R2423    | CONNECTOR, MALE 5/16 X 3/8 NPT       |
| 37                   | 28950    | TUBING ASSEMBLY, INLET               |
| N/S                  | R7591    | FLEXLINE W/SHUTOFF VALVE             |
| N/S*                 | R10416   | EXTENSION MODULE                     |
| N/S*                 | R11007   | CONTROL MODULE                       |
| N/S*                 | R2522    | SWITCH, ON/OFF                       |
| N/S*                 | R10418   | BATTERY BACKUP                       |
| N/S*                 | R10419   | AC ADAPTER                           |
| N/S*                 | R11006   | REMOTE CONTROL, AF MULTI-FUNCTION    |
| <b>DLCX36SP93N-1</b> |          |                                      |
| 19a                  | R10423   | PILOT ASSEMBLY, NAT                  |
| 22a                  | P305     | ORIFICE (NAT. GAS) 2.75mm            |
| 33a                  | R11044   | REGULATOR, MAXITROL 5.3" W.C.(NAT).  |
| N/S                  | R10430   | MINIMUM RATE SCREW - # 37            |
| <b>DLCX36SP93P-1</b> |          |                                      |
| 19b                  | R10424   | PILOT ASSEMBLY, LPG                  |
| 22b                  | P250     | ORIFICE (LP GAS) 1.65 mm             |
| 33b                  | R11045   | REGULATOR, MAXITROL 11.7" W.C.(LPG). |
| N/S                  | R10428   | MINIMUM RATE SCREW - # 52            |

N/S\*: Not Shown on Parts View. See page 39 for location and identification of parts.