

Atlanta 2450A/2450A-BR Parts List

Note that the quantities listed here below are the standard amounts that are found in each unit and not the number of items you need to order.

KEY NO.	PART NO.		DESCRIPTION
	MODEL 2450A	MODEL 2450A-BR	
1	101859	101859	Screw 1/4-20 x 1/2" (30 Required)
2	304026	304026	Flue Collar (3 Required)
3	154212	154212	Gasket (3 Required)
4	304004	304004	Outer Cabinet Top
5	400986	400986	Damper (3 Required)
6	304054	304054	Damper Mechanism
7	101021	101021	Screw 10-32 x 5/8"
8	149455	149455	Control Rod End
9	304003	304003	Cabinet Side—Right
10	104750	104750	Pin (2 Required)
11	400987	400987	Front Panel
12	304069	304069	Thermostat Clip
13	400988	400988	Hot Air Outlet Trim
14	400989	400989	False Hood Air Baffle
15	149457	149457	Damper Handle
16	149459	149459	Control Rod
17	149458	149458	Spring Stop (2 Required)
18	149456	149456	Spring
19	101858	101858	Screw 1/4-20 X 1/2" (26 Required)
20	304029	304029	Cabinet Front Air Channel
21	304030	304030	Front Panel Mounting Bracket (4 Required)
22	304000	304000	Cabinet Bottom
23	400949	400949	Firebox
24	101543	101543	Screw 1/4-20 X 3/4" (4 Required)
25	149460	149460	Spacer (2 Required)
26	205867	205867	Back Liner—Cast Iron
27	304001	304001	Cabinet Back
28	304002	302002	Cabinet Side—Left
29	102561	102561	Flatwasher 1/4" (3 Required)
30	102351	102351	Nut 1/4-20 (3 Required)

Woodman's Parts Plus
www.woodmanspartsplus.com

KEY NO.	PART NO.		DESCRIPTION
	MODEL 2450A	MODEL 2450A-BR	
31	400992	303995	Mantel Shield
32	400993	303996	False Hood Panel
33	104305	104305	Screw #A10 X 3/8" (8 Required)
34	400994	400994	Extension Trim Panel
35	400995	303997	False Side Panel—Left
36	400996	400996	Air Shutter
37	134027	134027	Thermo Disc
38	101212	101212	Screw 10-24 X 1/2" (2 Required)
39	134735	134735	Cable Clamp
40	104115	104115	Screw #A6 X 3/4" (3 Required)
41	134656	134656	Wire Lead (2 Required)
42	134330	134330	Terminal Block
43	400997	303998	False Side Panel—Right
44	134031	134031	Appliance Cord
45	134028	134028	Speed Control
46	134210	134210	Switch
47	147332	147332	Knob
48	147333	147333	Knob
49	400998	401000	Lower Front Panel
50	134030	134030	Wire Lead
51	102725	102725	Lockwasher #6 (4 Required)
52	102142	102142	Nut 6-32 (4 Required)
53	104305	104305	Screw #10 X 3/8" (6 Required)
54	304032	304032	Motor Bracket (2 Required)
55	134026	134026	Fan Motor (2 Required)
56	134350	134350	Fan Blade (2 Required)
57	304031	304031	Fan Collar (2 Required)
58	102162	102162	Nut 10-24
59	103021	103021	Flatwasher 3/16"
60	101307	101307	Screw 10-24 X 1"
61	102351	102351	Nut 1/4-20 (4 Required)
62	304068	304068	Air Shutter Linkage
63	104305	104305	Screw #A10 X 3/8"
64	134029	134029	Wire Lead
65	147206	147206	Grommet (2 Required)
66	104321	104322	Screw #A10 X 1/2" (4 Required)

Woodman's Parts Plus
www.woodmanspartsplus.com

KEY NO.	PART NO.		DESCRIPTION
	MODEL 2450A	MODEL 2450A-BR	
67	304050	304050	Screen (4 Required)
68	400991	400991	Door—Right
69	149452	149452	Handle—Right
70	149451	149451	Handle—Left
71	147331	147331	Knob (2 Required)
72	102613	102613	Flatwasher 3/8" (2 Required)
73	103305	103305	Cotter Pin (2 Required)
74	102204	102204	Nut 3/8-16 (4 Required)
75	304034	304034	Latch—Right
76	304033	304033	Latch—Left
77	149450	149450	Door Latch Rod (2 Required)
78	154211	154211	Gasket (4 Required)
79	178025	178025	Glass (4 Required)
80	304037	304037	Glass Retainer (8 Required)
81	104210	104210	Screw #A8 X 1/4" (16 Required)
82	400990	400990	Door—Left
83	101543	101543	Screw 1/4-20 X 3/4" (2 Required)
84	205887	205887	Grate Extension—Cast Iron (2 Required)
85	205886	205886	Grate—Cast Iron
86	400999	400999	Ash Pan
87	110840	110840	Installation Manual*

*not shown