

## BREF36/42, BREF36R/42R Electric Fireplace

### for Units with Ceramic Log Sets

Ref.	Description	BREF36	BREF36R	BREF42	BREF42R
1.	Log Set Complete	10004797	10004797	10004950	10004950
1a.	Log	10004470 (B111)	10004470 (B111)	10004945 (G1)	10004945 (G1)
1b.	Log	10004471 (B112)	10004471 (B112)	10004946 (G2)	10004946 (G2)
1c.	Log	10004472 (B113)	10004472 (B113)	10004947 (G3)	10004947 (G3)
1d.	Log	10004473 (B114)	10004473 (B114)	10004948 (G4)	10004948 (G4)
1e.	Log	--	--	10004949 (G5)	10004949 (G5)
2.	Heater Element	10004584	10004584	10004584	10004584
3.	Motor, AC, w/Terminals	10004262	10004262	10004262	10004262
4.	Rocker Switch (Illuminated)	10001393	10001393	10001393	10001393
5.	Thermostat - Heater Control	10002987	10002987	10002987	10002987
6.	Fan w/Bracket Assembly	10004695	10004695	10004695	10004695
7.	Sensor, 230°F Manual Reset	10004720	10004720	10004720	10004720
8.	Knob - Flame Speed, Heater Controls	10001639	10001639	10001639	10001639
9.	Light Filter - Ember Bed (Not shown)	10004518	10004518	10004957	10004957
10.	Plate Control Assembly	10006386	10006389	10006386	10006389
11.	Screen Tinted Plastic (Not shown)	10006381	10006381	10006391	10006391
12.	Ember Lava Rock	10004517	10004517	10004958	10004958
13.	Flame Generator Assembly	10003350	10003350	10004847	10004847
14.	Plate Log Support Assembly	10006380	10006380	10004853	10004853
15.	Socket Light Bulb Lower Assembly	10003568	10003568	10003568	10003568
16.	Limit Control, 175/20 DIF	10001172	10001172	10001172	10001172
17.	Transmitter	--	10005140	--	10005140
18.	Receiver	--	10005141	--	10005141
19.	CFM Wire Req'd (Not shown)	10004851	10006382	10004851	10006382