

- 1 Legs
 2 Leg strips
 3 Leg bottom
 4 Base front (never sent without doors)
 5 Flue stop
 6 Ash-pit door (prior to 1916)
 6 Ash-pit door, complete, 1916 and later
 7 Ash-pit doorplate (prior to 1916)
 8 Ash-pit door register
 9 Base side, left
 10 Base side, right
 11 Grate hole plate
 12 Base top
 13 Upper front
 14 Upper side, right
 15 Upper side, left
 16 Flue back
 17 Kettle top
 A17 Flue back top
 18 Kettle-top cover
 19 Upper back
 20 Main top
 21 Automatic cover
 23 Jacket front
 24 Jacket side, right
 25 Jacket side, left
 26 Jacket back, prior to 1914
 26 Jacket back, 1914 and later
 27 Jacket back plate
 A27 Water pan grill
 28 Jacket back top
 29 Hot-air drmpsr
 30 Elbow, right half
 31 Elbow, left half
 32 Low side mica door, right
 33 Low side mica door, left
 34 Low side mica door mica frame
 35 Upper side mica door, right
 36 Upper side mica door, left
 37 Upper side mica door mica frame
 38 Low front mica door, right
 39 Low front mica door mica frame, R
 40 Low front mica door, left
 41 Low front mica door mica frame, L
 46 Side mica domes
 47 Side mica dome mica frame
 48 Front mica dome
 49 Front mica dome mica frame
 51 Hearth plate
 52 Front nickel wings, complete, R.
 53 Front nickel wings, complete, L.
 54 Bottom flue strip, right
 55 Bottom flue strip, left
 56 Ash-pit bottom
 57 Ash-pit side, right
 58 Ash-pit side, left
 59 Back ash wall
 60½ Check damper
 61½ Check damper handle
 62 Ash flue
 63 Back flue strip, right
 64 Back flue strip, left
 65½ Direct damper
 65¼ Direct damper hinge
 66 Direct damper handle
 67 Fire pot
 68 Fire pot ring
 69 Shaking grate
 70 Shaker handle
 73 Duplex grate yoke
 75 Poker trap, short
 76 Poker trap, long
 78 Feed pot
 79 Magazine ring
 80 Gas flue plate
 81 Back air flue bottom cap
 82 Front rail hole plate
 207 Grate rollers
 208 Ash shelf
 211 Ash-pit door lever
 212 Ash-pit door catch
 322 Swing cover
 342 Upper front mica door, right
 343 Upper front mica door mica frame R
 344 Upper front mica door, left
 345 Upper front mica door mica frame L
 350 Foot rails
 352 Back nickel wing complete, right
 353 Back nickel wing complete, left
 371 Duplex grate back bar
 372 Duplex grate front bar
 374 Duplex grate gears
 422H Swing cover plate
 Ash pan
 Mica
 Poker
 Shaker
 Iron
 Water pan