

Breckwell SPC50 Parts List

Part No.	Description	Qty.
892300	Main Stove Body (Specify Color)	1
40599	Legs (Specify Color)	4
892301	Front Door Assembly (Specify Color)	1
40600	Front Door (Specify Color)	1
892302	Glass	1
88087	Glass Gasket	1
88066	Door Gasket	1
892303	Glass Retainers	7
892304	Hinge Pins	2
892308	Handle Assembly	1
892305	Cam	1
892306	Plastic Knob	1
892307	Brass Handle Body W/ Stud	1
892309	Side Door Assembly (Specify Color)	1
40601	Side Door (Specify Color)	1
892310	Handle	1
892311	Hinge Pins	2
88033	Rope Gasket	1
892312	Handle Catch	1
892319	Auger Assembly	1
892321	Auger Body	1
892322	Auger	1
892320	Auger Bushing/Bearing Assembly	1
40602	Baffles	2
892314	Primary/Secondary Air Tube Assembly	1
892315	Tube Weldment	1
892316	Primary Air Bushing	1
892317	Primary Air Nozzle	1
892318	Air Shutter Assembly	1
892313	Touchup Paint (Specify Color)	1
80664	4" Fan	2
80665	Electromagnet 12-Volt	1
80491	Microswitch	1
80661	Pressure Switch	1
80663	Hopper Thermodisc	1
80462	Receptacle, 3-Prong	1
80461	Cord, 3-Prong	1
80249	Burn Back Thermodisc	1
80610	Proof of Fire Thermodisc	1
80462	Auger Motor	1
892325	Fan Cover Grill	1