

Item No.	Description	Part Number
1	Cabinet Top AssemblyX510368
2	Cabinet Back AssemblyX510370
3	Cabinet Right Side.X510546
4	Door Cabinet AssemblyX510372
4A	Knob, Cabinet Door.	510127
5	Door Strike	510366
6	Front Frame Assembly.X510367
7	Cabinet, Left Side.X510547
8	Bottom Front Panel AssemblyX510374
9	Thermostat AssemblyX510530
10	Disc, Friction (Outside).	510185
11	Rod, Thermostat	510207
13	Housing Assembly, Thermostat.X510889
14	Disc, Friction (Inside)	510222
15	Spring, Thermostat.	510182
16	Washer, Flat.	120479
17	Cotter Key.	121267
18	Plate, Thermostat	510181
19	Knob, Thermostat.	510180

Item No.	Description	Part Number
22	Firebox Ass'y Complete.X510826
23	Gasket, Flue Collar	510335
24	Collar, Flue.	510783
25	Plate, Secondary Air.	510164
26	Pin, Hinge.	510197
27	Door, Load.	510536
28	Handle, Door.	510623
29	Eyelet Screw.	510578
30	Handle, Pull.	510577
31	Shield, Handle.	510654
32	Latch, Door	510774
33	Rail, Brick Right Assembly.X510869
33A	Rail, Brick Left Ass'y (Not Shown).X510868
33B	Retainer, Brick Access.	511075
34	Clamp, Smoke Baffle	510583
35	Brick, Fire	510161
36	Smoke Baffle.	510258
37	Grate Support Assembly.X510867
38	Heat Liner, Right Side.	510854
40	Ash PanX510861
41	Poker	510198
42	Door, Ash	510537
43	Gasket, Ash Door.	510625

Item No.	Description	Part Number
44	Pin, Draft Door	510165
45	Manifold, Draft	510162
45A	Gasket, Draft Manifold.	510830
46	Draft Door AssemblyX510815
47	Heat Shield, Floor.	510657
48	False Bottom.	510145
49	Rear Support AssemblyX510273
50	Bracket, End "Z".	510572
51	Cover (Bi-metal Thermostat)	510881
52	Bottom Cover Draft Manifold	510877
53	Right End Enclosure	510881
54	Top Cover Draft Manifold.	510878
55	Latch Catch Feed Door Ass'yX510776
55A	Washer, Spacer.	510630
56	Gear, Shaker.	510253
57	Lever, Shaker	510847
58	Gasket, Load Door	510626
59	Grate	510250
60	Retainer, Shaker (Back)	510255
61	Shaker, Grate (Left).	5 51
62	Shaker, Grate (Right)	
63	Retainer, Shaker (Front).	
64	Cotter, Key	121346