

CABINET ASSEMBLY

Item No.	Description	Part Number
1	Clip	510866
4	Rod, Top Stand	510849
5	Cabinet Assembly, Left Side	510547
6	Panel, Upper Front	512214
7	Frame and Screen Assembly	510672
8	Panel Assembly, Bottom Front	512284
10	Nut, 10-24	120717
11	Strike, Roller Catch	510366
12	Screw, #8-32 x 3/8	121407
13	Screw, #10-24 x 1/2	121227
14	Knob, Cabinet Door	510127
15	Cabinet Door Assembly	511709
16	Cabinet Assembly, Right Side	511972
17	Cabinet Back	512292
18	Cabinet Top	511710

THERMOSTAT

Item No.	Description	Part Number
19	Screw, #8 x 3/8 (2 Required)	121467
20	Knob, Thermostat	510180
21	Plate, Thermostat Trim	511724
22	Cotter Key 1/16 x 1-1/4	121267
23	Washer, 3/16 Flat	120759
24	Spring	510182
25	Channel, Thermostat Adjusting	511257
26	Clutch Plate	511258
27	Housing, Thermostat	511254
28	Friction Disc, Outside	510185
29	Coil Assembly, Bi-Metal Thermostat	511206
29A	Thermostat Assembly Complete (Includes Item No.'s 22, 23, 24, 25 26, 27, 28, 29, 32 and 33)	520407
30	Washer, #8 Flat	121233
31	Rod, Thermostat	511789
32	Bracket Assembly, Thermostat Housing	511715
33	Screw, #6 x 1/4 (4 Required)	121244
34	Nut, 6 - 32	121271
35	Draft Door Assembly	511660

Item No.	Description	Part Number
36	Draft Manifold	512321
37	Hinge Pin, Draft Door	510165
38	Tinnerman Clip	121269
39	Floor Shield	510657
40	Firebox Assembly	512140
41	Screw, 1/4 - 20 x 2 1/4" (2 Required)	121737
42	Secondary Air Adjusting Plate	510164
43	Flue Collar	510782
44	Gasket, Flue Collar	510335
45	Nut, 1/4 - 20 (6 Required)	120083
46	Hinge Pin (2 Required)	510197
47	Load Door	511285
48	Washer, 1/4 Flat	120479
49	Nut, 1/4 - 20 Hex Lock	121531
50	Latch	510774
51	Gasket, Load Door	511572
52	Handle, Load Door	510623
53	Eyelet Screw #8 - 32	510578
54	Handle, Wood	510577
55	Washer,#8 Flat	121233
56	Nut, 8 - 32 Lock	121402
57	Nut, 1/4 - 20 (6 Required)	120083
58	Washer, Firebrick Clamp (6 Required)	510453
59	Top "Z" Bracket Assembly (2 Required)	511290
60	Nut, 10 - 24 Hex (2 Required)	120717
61	Clamp, Smoke Baffle (2 Required)	510583
62	Screw, #10 - 24 x 1/2 (2 Required)	121227
63	Smoke Baffle	510258
64	Grate Support Assembly (2 Required)	510320
65	Washer, 1/4 Flat (6 Required)	121532
66	Nut, 1/4 - 20 (6 Required)	120083

Item No.	Description	Part Number
67	Firebrick (13 Required)	510161
68	Washer, 1/4 Flat (2 Required).....	121532
69	Plate, Brick Retainer	511289
70	Washer, Firebrick Clamp (2 Required).....	510453
71	Nut, 1/4 - 20 (2 Required)	120083
72	Rear Brick Retainer	511104
73	Nut, 1/4 - 20 (2 Required)	120083
74	Nut, 1/4 - 20 (2 Required)	120083
75	Rear Brick Support	511103
76	Washer, 1/4 Flat (2 Required).....	121532
77	Screw, #10 - 24 x 1-1/4 (One Each Required For Front Retainer and Rear Retainer)	121312
78	Nut, 1/4 - 20 (2 Required)	120083
79	Retainer, Shaker (Back End)	510255
80	Shaker Grate, Left Side	510251
81	Nut, 10 - 24 Hex (2 Required)	120717
82	Grate Frame	510250
83	Shaker Grate, Right Side	510252
84	Retainer, Shaker (Front End)	510254
85	Cotter Key (2 Required)	120130
86	Gear, Shaker Grates (2 Required)	510253
87	Shaker Handle	510256
88	Liner, Firebox (Right Side)	510155
89	Ash Pan	511889
90	Handle, Ash Door.....	512004
91	Ash Door	511286
92	Hinge Pin (2 Required)	510197
93	Gasket, Ash Door.....	511573
94	Latch	510774
95	Washer, 1/4 Flat	121532
96	Nut, 1/4 - 20 Hex Lock	121531