

KEY NO.	PART NO.	DESCRIPTION	CFS26PT, S26PTA		QTY.
			CFS26NT, S26NTA		
1	105441-01	Log Set	•	•	1
2	104286-01	ODS Pilot	•	•	1
	104285-01	ODS Pilot	•	•	1
3	098249-01	ODS Nut	•	•	2
4	109053-01	Burner Outlet Tube	•	•	1
5	111124-01	Burner Retainer Spring	•	•	1
6	099056-29	Burner Orifice Injector	•	•	1
	099056-27	Burner Orifice Injector	•	•	1
7	101329-26	Gas Control Valve Kit	•	•	1
	101329-20	Gas Control Valve Kit	•	•	1
8	102980-01	Burner	•	•	1
9	099387-09	Pilot Tube	•	•	1
10	098271-10	Ignitor Cable	•	•	1
11	101381-01	Piezo Ignitor and Cover	•	•	1
12	098867-10	Regulator	•	•	1
	098867-14	Regulator	•	•	1
13	109052-01	Inlet Tube	•	•	1
14	105990-01	Pilot Shield	•	•	1
PARTS AVAILABLE — NOT SHOWN					
	100563-01	Warning Plate	•	•	1
	101054-01	Lighting Instructions Plate	•	•	1

KEY NO.	PART NO.	DESCRIPTION	CFS26		QTY.
			S26		
1	108942-01CK	Top Panel, Stove	•	•	1
2	**	Pedestal Stove	•	•	1
3	108934-01CK	Stove Base	•	•	1
4	**	Stove Back Panel	•	•	1
5	108932-01CK	Louver Panel	•	•	1
6	105657-01	Blower Bracket	•	•	2
7	107363-01	Door	•	•	1
8	**	Firebox Back Panel	•	•	1
9	**	Firebox Floor	•	•	1
10	108939-01CK	Firebox Top Assembly	•	•	1
11	110419-01CK	Screen Assembly	•	•	1
12	101382-01	Valve Bracket	•	•	1
13	108978-01CK	Stove Top Trim	•	•	1
14	108944-01	Brass Trim, Firebox	•	•	2
	108944-02	Black Trim, Firebox	•	•	2
15	105576-01	Knob	•	•	1
	102874-01	Knob	•	•	1
16	101386-02	Door Hinge	•	•	2
17	099230-02	Shoulder Screw	•	•	4
18	108945-01CK	Heat Deflector	•	•	1
PARTS AVAILABLE — NOT SHOWN					
	101054-01	Lighting Instructions Plate	•	•	1
	100563-01	Warning Plate	•	•	1
	104108-06	Metallic Black Touch-Up Paint Kit	•	•	1

** Not a field replaceable part.