

# PARTS LIST

## MAIN ASSEMBLY

Part #	Description	Part #	Description
1)	076-201 Cast Stove Top		
2)	076-211 Cast Pedestal	*	Firebox Assembly
3)	156-211 Surround Bottom	940-366/P	Neoceram Glass
4)	156-513 Curved Door Assembly		
5)	156-261 Thin Surround		
6)	076-921 Side Shield (Black Set)	918-896	Manual
	076-927 Side Shield (Stainless Set)		
7)	156-519 Door Catch Assembly		
8)	076-516 Heat Shield		
9)	156-523 Door Hinge Assembly		
10)	942-110 Ash drawer plug		
11)	076-911 Ash Drawer Assembly		
12)	076-004 Fan Opening Cover		
13)	076-010 Back Shield		
14)	074-954 Air tube		
15)	033-953 Air tube		
16)	073-955 Baffle set		
17)	076-913 Ashlip		

\* Not available as a replacement part

### Fan Assembly Parts List

	Part #	Description
1)	076-201	Fan Housing Front
2)	222-022	Fan Housing Bottom
3)	222-036	Sensor Mount
4)	200-227	Fan Bracket Right Hand
5)	200-228	Fan Bracket Left Hand
6)	200-229	Fan Housing Back
7)	910-157/P	Fan
8)	910-142	Thermodisc

## Firebrick Parts List

	Part #	Description
1)	020-960	Firebrick Set
2)	033-953	Air Tube - 3/4" (Qty: 4)
3)	020-957	Baffle (set)

[www.woodmanspartsplus.com](http://www.woodmanspartsplus.com)