

KEY NO.	PART NUMBER		DESCRIPTION	QTY.
	CS26PT	CS26NT		
1	113067-01	113067-01	Log Set	1
2	104286-01	104285-01	ODS Pilot	1
3	098249-01	098249-01	ODS Nut	2
4	112380-01	111331-15	Burner Outlet Tube	1
5	098522-28	098522-29	Thermostat Gas Valve	1
6	099056-29	099056-27	Burner Orifice Injector	1
7	101382-01	101382-01	Valve Bracket	1
8	102963-02	102963-02	Burner	1
9	099387-09	099387-09	Pilot Tube	1
10	098271-10	098271-10	Ignitor Cable	1
11	101381-01	101381-01	Piezo Ignitor and Cover	1
12	098867-10	098867-14	Regulator	1
13	112381-01	112381-01	Inlet Tube	1
14	**	**	Stove Firebox Bottom	1
15	099211-01	099211-01	Screw 10-26 x 2	2
PARTS AVAILABLE – NOT SHOWN				
	100563-01	100563-01	Warning Plate	1
	101054-01	101054-01	Lighting Instructions Plate	1

** Not a field replaceable part.

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	112983-01CX	Stove Pedestal	1
2	112984-01CX	Left and Right Stove Sides	2
3	112985-01CX	Stove Top	1
4	112986-01BR	Stove Firebox Back	1
5	112987-01CX	Stove Base	1
6	112988-01BR	Stove Screen Assembly	1
7	099230-02	Screw, HWH Shldr AB 1-x.3	4
PARTS AVAILABLE – NOT SHOWN			
	101054-01	Lighting Instructions Plate	1
	100563-01	Warning Plate	1
	105657-01	Blower Bracket	2