

DEF33/36 Electric Fireplace

Ref.	Description	AE4 DEF33	BE2 DEF36
1.	Log Set Complete	10004401	10004474
1a.	Log	10004457 (A27)	10004470 (B111)
1b.	Log	10004458 (A28)	10004471 (B112)
1c.	Log	10004459 (A29)	10004472 (B113)
1d.	Log	10004460 (A30)	10004473 (B114)
1e.	Log	10004461 (A31)	N/A
1f.	Log	10004462 (A32)	N/A
2.	Fan/Heater	10004198	10004198
3.	Motor 12V DC - Flame Generator	10001978	10001978
4.	Rocker Switch (Illuminated)	10001393	10001393
5.	Thermostat - Heater Control	10001971	10001971
6.	Potentiometer - Flame Speed Control	10001168	10001168
7.	Circuit Board - Flame Speed Control	10001589	10001589
8.	Knob - Flame Speed, Heater Controls	10001639	10001639
9.	Trim-Frame Window (PB) (w/ 2 magnets)	55005	57480
10.	Light Filter - Ember Bed (Not Shown)	10004447	10004518
11.	Light Diffuser Screen (Not Shown)	10003380	10004521
12.	Screen Tinted Plastic (Not Shown)	10003381	10004522
13.	Glass with Gasket 4W-25	10001704	10003349
14.	Gasket Glass	10001881	10001881
15.	Frame Window Assembly	10003432	10003352
16.	Ember Lava Rock	10004400	10004517
17.	Flame Generator Assembly	10003350	10003350
18.	Top Panel Radiant	10004391	10004484
19.	Bottom Panel Radiant	10004161	10004162
20.	Plate Log Support Assy.	10004455	10004488
21.	Facia Control Assembly	10004389	10004480
22.	Breaker Circuit Manual Reset	10003093	10003093
23.	Cord Power 16/3 HPN with Terminals	10003095	10003095
24.	Receptacle .093" Pin & Socket	10003104	10003104
25.	Plug .093" Pin & Socket	10003105	10003105
26.	Socket Light Bulb Lower Assembly	10003127	10003127