

DEF33/36 Electric Fireplace

Ref.	Description	AE3	BE1
		DEF33	DEF36
1.	Log Set Complete	10003628	10003629
1a.	Log Top Left	N/A	B99
1b.	Log Top Right	N/A	B100
1c.	Log Bottom	N/A	B101
2.	Fan/Heater Assembly w/bracket	10001815	10001815
3.	Motor 12VDC - Flame genertor	10001978	10001978
4.	Switch Rocker	53606	53606
5.	On/Off Switch (Illuminated)	10001393	10001393
6.	Thermostat - Heater Control	10001971	10001971
7.	Potentiometer - Flame Speed Control	10001168	10001168
8.	Circuit Board - Flame Speed Control	10001589	10001589
9.	Knob - Flame Speed, Heater Controls	10001639	10001639
10.	Top Louvre Assembly	10000292	10000037
11.	Bottom Louvre Assembly	10000293	10000038
12.	Hinge Access Door	52356	52356
13.	Trim-Frame Window (PB) (w/2 magnets)	55005	57480
14.	Light Filter - Ember Bed (Not Shown)	10001259	10003111
15.	Light Diffuser Screen (Not Shown)	10003380	10003108
16.	Screen Tinted Plastic (Not Shown)	10003381	10003109
17.	Glass with Gasket 4W-25	10001883	10003349
18.	Gasket Glass	10001881	10001881
19.	Frame Window Assembly	10003432	10003352
20.	Light Diffuser - ember Bed (not shown)	10001536	10003110
21.	Flame Generator Assembly	10003350	10003350
22.	Top Panel Radiant	10003309	10003074
23.	Bottom Panel Radiant	10003310	10003079
24.	Access Panel Radiant	10003311	10003082
25.	Facia Control Assembly	10003379	10003348
26.	Breaker Circuit Manual Reset	10003093	10003093
27.	Cord Power 18 / 3 HPN with Terminals	10003095	10003095
28.	Receptacle .093" Pin & Scket	10003104	10003104
29.	Plug .093" Pin & Socket	10003105	10003105
30.	Socket Light Bulb Lower Assembly	10003127	10003127