

# DEF36S2 Electric Fireplace

Ref.	Description	BE1 DEF36S2
1.	Log Set Complete	10003647
1a.	Log Top Left	B103
1b.	Log Top Right	B104
1c.	Log Bottom	B102
2.	Fan/Heater Assembly w/bracket	10001815
3.	Motor 12VDC - Flame genertor	10001978
4.	Switch Rocker	53606
5.	On/Off Switch (Illuminated)	10001393
6.	Thermostat - Heater Control	10001971
7.	Potentiometer - Flame Speed Control	10001168
8.	Circuit Board - Flame Speed Control	10001589
9.	Knob - Flame Speed, Heater Controls	10001639
10.	Top Louvre Assembly	10000037
11.	Bottom Louvre Assembly	10000038
12.	Hinge Access Door	52356
13.	Trim-Frame Window (PB) (w/2 magnets)	57480
14.	Light Filter - Ember Bed (Not Shown)	10003514
15.	Light Diffuser Screen (Not Shown)	10003108
16.	Screen Tinted Plastic (Not Shown)	10003109
17.	Glass with Gasket 4W-25	10003349
18.	Gasket Glass	10001881
19.	Frame Window Assembly	10003552
20.	Light Diffuser - ember Bed (not shown)	10003513
21.	Flame Generator Assembly	10003350
22.	Top Panel Radiant	10003074
23.	Bottom Panel Radiant	10003079
24.	Access Panel Radiant	10003082
25.	Facia Control Assembly	10003348
26.	Breaker Circuit Manual Reset	10003093
27.	Cord Power 16 / 3 HPN with Terminals	10003095
28.	Receptacle .093" Pin & Scket	10003104
29.	Plug .093" Pin & Socket	10003105
30.	Socket Light w/Wiring Assembly	10003127